

SMLC Model 30, 80 & 160

Installation & Operation Manual

SMLC-002c

Copyright © 2006

ORMEC Systems Corp.

All Rights Reserved

19 Linden Park
Rochester, NY 14625
(585) 385-3520

June 28, 2006

Copyright Notice

Copyright © 2005-6 by ORMEC Systems Corp. All rights reserved. This manual and any software that it may describe, remain the exclusive property of ORMEC Systems Corp. No part of either may be reproduced in any form without the prior written permission of ORMEC.

Trademark Notices

ServoWire™ and ServoWire Pro™ are trademarks of ORMEC Systems Corp.
For more information, visit www.ORMEC.com

QNX® and **Neutrino®** are registered trademarks of QNX Software Systems Ltd.

WAGO® is a registered trademark of WAGO Corporation.

MODBUS® is a registered trademark of Schneider Electric.

Warranty

ORMEC extends no warranty with respect to the merchantability or fitness of this product for any particular purpose. It is the customer's responsibility to determine whether it is suitable for the specific application and whether it meets performance, reliability and safety requirements when used in that application. ORMEC reserves the right to make improvements to the product as well as this documentation at any time without notice.

Terms and Conditions

All hardware and software sold or otherwise provided by ORMEC is made available subject to ORMEC's published Standard Terms and Conditions of Sale.

Table of Contents

SMLC Model 30, 80 & 160	i
1 Welcome	1
2 SMLC General System Description	3
2.1 Features	3
Hardware Features	4
Software Features	4
2.2 SMLC Support Software	6
CoDeSys - Development Software	6
ServoWire Pro - System Configuration Software	6
WAGO Ethernet I/O	6
2.3 SMLC Models	7
3 ServoWire Motion & Logic Controller Installation	9
3.1 Installation	9
Safety Related Guidelines for Installation in the European Union.....	9
Receiving and Inspection.....	10
Panel Mounting and Environment.....	10
4 SMLC System Components	11
J10 – ServoWire IEEE 1394 Interface Port	12
J11 – ServoWire IEEE 1394 Interface Port	12
J12 – Keyboard/Mouse Interface Connector	13
J13 – Digital I/O Connector.....	14
Figure 6, <i>Schematic of Discrete Inputs IN1'-IN8'</i>	14
Figure 7, <i>Schematic of Discrete Outputs OUT1'-OUT8'</i>	15
J14 – USB Port	15
J15 – USB Port	15
J16 – Ethernet Port EN1	16
J17 – Ethernet Port EN0.....	16
J18 – Analog I/O Connector	17
J19 – VGA Connector	17
J20 – Development Serial Port COM1 - RS232	18
J21 – SMLC HMI Serial Port COM2 - RS232	18
J22 – SMLC User Serial Ports COM3 - RS232	18
J23 – SMLC User Serial Ports COM4 - RS232 (Model 160 only)	18
TB1– Input AC Power Connector	19
LEDs	19
Reset Pushbutton	19
System Card	19
5 System Power Wiring & Interlocks	21
Emergency-Stop / Quick-Stop and Drive Ready Configuration.....	22
Emergency Stop Input:	22
Quick Stop Input:	22
ServoWire Pro Drive Properites.....	22
Selecting the ServoWire drive input behavior	23
Selecting the ServoWire drive output behavior	23

5.1 ServoWire Drive Input / Output	24
SDM Servodrive I/O	24
SMM Servodrive I/O	25
IN4 or [OUT4 or Drive Ready] *See note.	25
SWM Servodrive I/O	25
6 System Operation	27
6.1 SMLC Status LED's	27
6.1.1 Power-up.....	27
6.2 SMLC Non-volatile memory	29
6.3 Specifications	30
SMLC Mechanical and Environmental Specifications	30
Input AC Power Ratings	31
Battery Power Specifications	31
Digital I/O Power requirements.....	31
Digital Input Specifications.....	31
Digital Output Specifications.....	32
Analog Input Specifications	32
Analog Output Specifications.....	32
Development port COM1 Specifications.....	33
HMI Serial Port COM2 Specifications.....	33
Serial Port COM3 and COM4 (Model 160 only) Specifications.....	33
7 WAGO Installation & Operation	35
General Purpose I/O	35
7.1 WAGO Installation	36
Setting the WAGO IP Address.....	36
7.2 WAGO Part List	39
WAGO Digital Input Modules	39
WAGO Digital Output Modules	39
WAGO Analog Input Modules.....	40
WAGO Analog Output Modules.....	40
WAGO Specialty Modules	41
WAGO Power Supplies and Accessories.....	41
8 Getting Started	43
8.1 Preparation for Test Run	43
ServoWire Motion & Logic Controller Checklist.....	43
Servomotor Checklist.....	44
Applying System Control Power	44
8.2 Setting up SMLC Serial communications	45
Initializing the Communications Connection.....	45
Disconnecting serial communications from SMLC and your PC.....	45
Troubleshooting Connection Problems	45
8.3 SMLC Ethernet Configuration	45
Default SMLC Ethernet Port Addressing	45
Assigning SMLC Ethernet Port Addressing in ServoWire Pro.	46
8.4 ServoWire Pro Development Software	47
Test Running Your SMLC System.....	47
Test Running Your SMLC System.....	47
9 Product History	48
9.1 Determining Hardware Revision Numbers	48
9.2 SMLC Model 30, 80 and 160 History	48
10 Maintenance & Troubleshooting	49

10.1 ORMEC Product Support.....49
10.2 SMLC Troubleshooting.....50
 No LEDs Lit on SMLC.....50
 SMLC Does Not Complete the Power Up Sequence.....50

11 Terms & Mnemonics..... 51

Appendix A - SMLC Installation Diagrams 54
 SMLC – Installation Dimensions..... 54

Appendix B – System Wiring Drawings..... 56
 ServoWire SDM Drives 120 ~ 460 VAC System Wiring.....56
 ServoWire SMM Drives 120 ~ 460 VAC System Wiring57
 ServoWire SMM Drive 12 ~ 96 VDC System Wiring58

Appendix C – SMLC Interface Cables & Accessories 59
 Serial Communications Null Modem Cable to PC.....59
 Profibus Cable Drawing.....60

Appendix D – ServoWire Drive Fault Codes..... 61
 ServoWire Drive “A” Fault Codes61
 ServoWire Drive “b” Fault Codes.....64
 ServoWire Drive “C” Fault Codes65
 ServoWire Drive “E” Fault Codes66
 ServoWire Drive “F” Fault Codes.....68
 ServoWire Drive Internal Fault Codes71

List of Tables

Table 1, ServoWire: IEEE 1394 Cable part numbers.12
Table 2, Keyboard/Mouse Connector (J12) pin-out.....13
Table 3, Digital I/O connector (J13) pin-out.....14
Table 4, Ethernet Port (J16 & J17) pin-out.16
Table 5, Ethernet Cables & Accessories part numbers.16
Table 6, Analog I/O connector (J18) pin-out.17
Table 7, CRT Connector (J19) pin-out.....17
Table 8, RS-232 Serial Port Connector (J20,J21,J22,J23) pin-out.....18
Table 9, Power connector (TB1) pinout.19
Table 10, SMLC Status LED's.....27
Table 11, SMLC Controller General Specifications.....30
Table 12, SMLC Controller Mechanical and Environmental Specifications30
Table 13, SMLC and Accessories Input Power31
Table 14, SMLC Battery Power.....31
Table 15, Digital I/O Power requirements31
Table 16, Digital input specifications.....31
Table 17, Digital output specifications.....32
Table 18, Analog input specifications32
Table 19, Analog output specifications32
Table 20, SMLC Development Serial Port.....33
Table 21, SMLC HMI Serial Ports33
Table 22, SMLC Serial Ports COM3 & COM4.....33

List of Figures

Figure 1 , SMLC System.....	3
Figure 2 , SMLC with SMM ServoWire drives.....	4
Figure 3 , SMLC Models 30 , 80 and 160	7
Figure 4 , SMLC Model 30 with four SM ServoWire drives	12
Figure 5 , Keyboard Connector (J12) connector.....	13
Figure 6 , Schematic of Discrete Inputs IN1'-IN8'	14
Figure 7 , Schematic of Discrete Outputs OUT1'-OUT8'.....	15
Figure 8 , SMLC - Ethernet Connector (J16 & J17) connector.....	16
Figure 9 , SMLC - CRT Connector (J19) connector.....	17
Figure 10 , RS-232 Serial Port Connector (J20,J21,J22,J23) Pinout.....	18
Figure 11 , ServoWire Pro Drive Proprieties	22
Figure 12 , ServoWire Pro E-Stop / Quick Stop configuration.....	23
Figure 13 , ServoWire Pro Drive Ready configuration.....	23
Figure 14 SAC-SDM Servodrive I/O	24
Figure 15 SAC-SMM Servodrive I/O.....	25
Figure 16 SAC-SWM Servodrive I/O.....	25
Figure 17 , WAGO Launch BootP server:	36
Figure 18 , WAGO Launch Notepad.....	36
Figure 19 , WAGO edit BootPtab.txt.	36
Figure 20 , WAGO Start BootP Server	37
Figure 21 , ServoWire Pro IP Address.....	45
Figure 22 , ServoWire Pro Ethernet Ports IP Address	46
Figure 23 SMLC Mounting dimensions - height and width	54
Figure 24 SMLC Mounting dimensions – depth.....	55

Chapter 1

Welcome

1 Welcome

This manual covers the ORMEC's ServoWire Motion & Logic Controller (SMLC) and accessories used with it. It provides a detailed description of the SMLC hardware and needed information for installing, operating and "getting started" with a SMLC system.

The manual is divided into the following chapters:

Chapter 1	Welcome introduces you to this manual and its organization.
Chapter 2	General Description - Overview of the SMLC product family.
Chapter 3	SMLC Installation provides instructions for installing the SMLC and detailed descriptions of all the hardware interfaces. It explains the power up and initial configuration operation as well as the LED status indicators. This chapter also provides detailed environmental, mechanical, and electrical interface specifications for the SMLC Controller.
Chapter 4	WAGO I/O Installation provides instructions for installing the WAGO and detailed descriptions of all the hardware interfaces, as well as an explanation of the LED status indicators. This chapter also provides detailed specifications for the electrical interface specifications for the WAGO I/O.
Chapter 5	Getting Started provides detailed instructions on how to communicate and run your SMLC unit for the first time.
Chapter 6	Product History provides a chronological revision history for the ServoWire Motion & Logic Controller.
Chapter 7	Maintenance & Troubleshooting provides tips for maintaining and troubleshooting your SMLC system.
Chapter 8	Terms & Mnemonics provides definitions for term's specific to Motion Control and/or ORMEC's Motion Control products.
Appendix	Appendixes contain detailed drawings, which document the SMLC dimensions, system interface, as well as associated interface cables and accessories. See the Table of Contents for details.

This manual concentrates on providing SMLC hardware and cabling documentation. Detailed information on ORMEC's SMLC programming language is found in the on-line **SMLC Help**.

To obtain the latest version of the SMLC Help visit ORMEC's site on the World Wide Web at ***<http://www.ORMEC.com>***, or call the ORMEC Service Department at **1-(585) 385-3520**.

The functionality of certain portions of the SMLC hardware is dependent on the firmware and optional SMLC hardware version used.

Throughout this manual the term SMLC refers to Models 30, 80 and 160 unless otherwise indicated. SMLC Models 05 (Lite) and 10 have their own installation and operation manual, SML-001.

Chapter 2

General Description




Figure 1, SMLC System

2 SMLC General System Description

2.1 Features

- **Application Development - CoDeSys IEC 61131-3 Programming:**
IEC 61131-3 is an open standard for developing application programs for motion and I/O control, running on a single processor. See: www.3s-software.com & www.PLCopen.org
- **Operating System - QNX Neutrino Real Time Operating System (RTOS):**
In QNX Neutrino, only the most fundamental OS primitives (e.g. signals, timers, scheduling) are handled in the kernel itself. All other components – drivers, file systems, protocol stacks, user applications – run outside the kernel as separate, memory-protected processes. Fault resilience is built right in. See: www.QNX.com

- **System configuration & diagnostic's - ServoWire Pro:**
ServoWire Pro provides an integrated suite of configuration, diagnostic and maintenance utilities that assist in the development and on-going support of ServoWire SM systems.
- **All Digital - IEEE-1394 Networked Servodrives:**
Connection of up to 16 ServoWire Drives with up to a 2 kHz loop update rate, without the need to purchase additional hardware or software. All digital servo drive network using open standard IEEE 1394 (FireWire) interface hardware and cabling.
- **ServoWire Drive I/O:**
High speed ServoWire Drive I/O is used to capture axis position (example: registration) and control (start / stop) motion.
- **General Purpose I/O - WAGO, Ethernet (MODBUS/TCP) and FireWire I/O:**
Compact, highly reliable and cost effective, with a wide variety of Input / Output modules.

Hardware Features

ORMEC's ServoWire Motion & Logic Controller uses a PC-based system packaged using off the shelf hardware in a wall-mount chassis for easy installation.

SMLC hardware includes:

- CPU - Celeron or Pentium Class processors
- 2 Ethernet Ports – 10/100baseT (/1000baseT on model 160).
- FireWire (IEEE 1394) network interface.
- 3 serial ports (4 on the Model 160)
- Development, HMI, Keyboard connectors.
- Optional PC-104/+ expansion
- Built-in digital and analog I/O



Figure 2, SMLC with SMM ServoWire drives

SMLC memory includes:

- 128 Mb Dynamic RAM - Random Access Memory (volatile)
- 128Mb Removable Compact Flash memory for application program and data storage.
- 32 Kb Battery backed static RAM used for non-volatile data storage.

The all-digital ServoWire servo drive provides support for a variety of actuator technologies, including brushless rotary and linear motors, DC brush motors and voice coils. The drives are configured over the ServoWire 1394 network, eliminating all manual configuration and offline configuration utilities, reducing the cost and complexity of maintaining the motion control system.

Software Features

ORMEC has selected the highly reliable QNX Neutrino as the SMLC real time operating system (RTOS). The use of a RTOS in the SMLC facilitates the integration of new functionality and eases product lifecycle maintenance by allowing for easy migration to new and more powerful hardware platforms, as they become available.

To implement the ServoWire Controller's programming, ORMEC has partnered with 3S to integrate high performance ServoWire Soft Motion technology with CoDeSys IEC 61131-3 software. CoDeSys covers all five IEC 61131-3 standard compliant languages, and is incorporated in over one hundred OEM partner products. All application motion and I/O control

is implemented in a single program running on one processor, without the delays and timing issues associated with separate processor cards in PCs and PLC racks.

For the motion control programming, ORMEC has implemented PLCopen Motion Control function blocks. Powerful features have been added to the open standard motion control function blocks, allowing motions to be loaded into a motion queue for sequential operation initiated independent of the I/O scan rate. Motions in the queue can be automatically repeated, simplifying application programming, and triggered by high-speed sensor inputs at the servo command Loop Rate (faster than the I/O scan rate). It is also possible to easily superimpose incremental time-based and geared motions on top of a constant motion gear ratio, without the need to develop cam profiles. For more details, read the help file **SMLCsoftware.chm**.

2.2 SMLC Support Software

CoDeSys - Development Software

CoDeSys IEC 61131-3 programming with PLCopen motion function blocks provides open standard tools for developing application programs for motion and I/O control. General-purpose I/O options are fully supported using WAGO's 750 Series.

The IEC 61131-3 standard suite of programming languages provides an integrated set of software tools and graphical interfaces to meet a wide range of software development needs:

- Relay Ladder Logic (LD)
- Structured Text (ST)
- Sequential Function Chart (SFC)
- Function Block Diagram (FBD)
- Instruction List (IL) tools
- CoDeSys also includes a sixth language, Continuous Function Chart (CFC)

Development Software Part Number:

CDS-SDK/C - CoDeSys Developers Kit (one seat), CD-ROM, incl. ServoWire Pro, Wago BootP server, serial communication cable and one year of maintenance & support.

ServoWire Pro - System Configuration Software

ServoWire Pro provides an integrated suite of configuration, diagnostic and maintenance utilities that assist in the development and on-going support of ServoWire systems. The software is designed to run on the development PC. ServoWire Pro is used to create a project file containing all of the motor and drive configuration information, which is then downloaded to the SMLC. ServoWire Pro includes the following utilities:

- | | |
|------------------|---|
| • SWSetup | Menus and software wizards to simplify drive configuration & set-up |
| • SWMonitor | Diagnostic utilities for monitoring drive and network performance |
| • SWTune | Tuning scope and software for optimizing motion performance |
| • SWUpgrade | Tools for upgrading ServoWire SMM drives to latest firmware |
| • SWScope | Monitor real-time parameters and dynamic system performance |
| • SMLCUpgrade | Tool for upgrading SMLC firmware |
| • SMLC utilities | Manage files on the SMLC and configure the SMLC Ethernet ports |

WAGO Ethernet I/O

Wago BootP server is used to configure the IP address of Wago Ethernet bus couplers.

2.3 SMLC Models

This manual covers three SMLC Models: Model 30, Model 80 and Model 160.

The **SMLC Model 30** can control up to 3 ServoWire drives where each drive can contain one motor axis and one auxiliary (pacer) axis. Each drive can be physical or virtual. A virtual drive may have a virtual motor, but not a virtual pacer.

The **SMLC Model 80** can control up to 8 ServoWire drives where each drive can contain one motor axis and one auxiliary (pacer) axis. Each drive can be physical or virtual. A virtual drive may have a virtual motor, but not a virtual pacer.

The **SMLC Model 160** can control up to 16 ServoWire drives where each drive can contain one motor axis and one auxiliary (pacer) axis. Each drive can be physical or virtual. A virtual drive may have a virtual motor, but not a virtual pacer.



Figure 3, SMLC Models 30 , 80 and 160

Chapter 3

SMLC Installation

3 ServoWire Motion & Logic Controller Installation

3.1 Installation

Safety Related Guidelines for Installation in the European Union

General: ORMEC product manuals are written to provide information required for the proper use of the equipment in the intended operation. They are written for technically qualified personnel such as engineers, programmers and maintenance specialists who have been trained in the application of automation control systems.

Proper Use: The equipment and/or system or components may only be used as described in the product manuals.

Guidelines: ORMEC motion control products generally form a part of a larger system or installation. These guidelines are intended to help integrate ORMEC products into the system.

- Since these products are component devices, overall automated system safety is beyond the scope of the product manuals and is the responsibility of the integrator.
- Compliance with EN292-1 and EN292-2 (Safety of Machinery) as well as EN60204 (Electrical Equipment of Industrial Machines) must be observed during the design phase.
- Only qualified personnel should be allowed access to the equipment.
- Opening the housing or protective covers may expose dangerous voltages.
- Emergency tripping devices in accordance with EN60204 must be effective in all operating modes of the automation equipment.
- Measures must be taken when interfacing the inputs and outputs of the automation equipment to prevent an undefined state from being assumed in the case of a wire break in the signal lines.
- The motion controller is a programmable device with the application program being written by the person integrating it into the machine. A qualified person should write this program. Measures must be taken to verify that the program written does not cause dangerous and unwanted machine operation.
- These systems are of rugged design and intended for general-purpose service. However, as with any equipment, the more stressing the service conditions the worse

is the reliability and some benefit may be expected when real service conditions are better than the worst service conditions specified in the product manual and Standards. Some applications may require consideration of special packaging, cooling, electrical noise protection, etc. for reliable operation.

Receiving and Inspection

ORMEC ServoWire Motion & Logic Controller and their associated accessories are put through rigorous tests at the factory before shipment. After unpacking, however, check for damage, which may have been sustained in transit. Check the SMLC and any of the accessories for bent or broken components, loose bolts or screws and any other physical damage before installing.

NOTE: Use the original SMLC packaging material for shipping units.

Included with your SMLC is a CD package, which contains installation disks, Users Guide, license agreement, and registration card. Please open this package, read the license agreement, and fill out and return the registration card. SMLC operates on the QNX operating system, with the RUN-TIME License pre-installed on your SMLC.

Panel Mounting and Environment


Panel Mounting data is available in the SMLC Mechanical and Environmental Specifications section of this chapter. The controller's environment should be maintained as follows:

- Operating temperature should be between 0 and 50C (32°F to 122°F).
- The SMLC should be mounted in a grounded metal enclosure
- If the electrical panel is subject to vibration, mount the unit on shock absorbing material.
- Avoid use in corrosive atmospheres, which may cause damage over time.
- Select a location with minimum exposure to oil, water, hot air, high humidity, excessive dust or metallic particles.
- The proper mounting orientation for the SMLC is vertical on a panel using the mounting holes (3) provided on the base plate.

Chapter 4

SMLC System Components

4 SMLC System Components



J10/J11 – ServoWire 1394b ports

LEDs - Watchdog OK, Run, User, Fault, System, 24v power, 5v power, Disk activity

Reset Pushbutton

J12 – Keyboard port

J13 – Digital I/O connector

J14/15 – USB ports

J16 – EN1

J17 – EN0

System Card – Compact Flash - **WARNING – Do not install or remove the system card with power applied to the SMLC!**

J18 – Analog I/O connector

J19 – VGA connector

J20 – Development Serial Port – COM1

J21 – HMI /User Serial Port - COM2

J22 – User serial port - COM3 (J22)

J23 – User serial port – COM4 (Model 160 only)

TB1 – Input AC Power connector (on top, not shown)

J10 – ServoWire IEEE 1394 Interface Port
J11 – ServoWire IEEE 1394 Interface Port



The SMLC ServoWire interface uses 9-pin bilingual IEEE 1394b connectors. Connections from the SMLC to the ServoWire Drives with 6-pin IEEE 1394a connectors are made using bilingual ServoWire cables (CBL-SW-BA-##). Connections between the drives are made using “standard” ServoWire cables (CBL-SW-A-##).



Figure 4, SMLC Model 30 with four SM ServoWire drives

ServoWire Cables	Description
CBL-SW-BA-3	ServoWire Cable, 9 pin to 6 pin, 3.3 ft
CBL-SW-BA-6	ServoWire Cable, 9 pin to 6 pin, 6.6 ft
CBL-SW-BA-14	ServoWire Cable, 9 pin to 6 pin, 14.8 ft
CBL-SW-A-2	ServoWire Cable, 2 ft. (0.7 M)
CBL-SW-A-6	ServoWire Cable, 6.6 ft. (2.0 M)
CBL-SW-A-14	ServoWire Cable, 14.8 ft. (4.5 M)
CBL-SW-A-33	ServoWire Cable, 33 ft. (10 M)

Table 1, ServoWire: IEEE 1394 Cable part numbers.

J12 – Keyboard/Mouse Interface Connector

The Keyboard Interface, standard on all SMLC controllers, is a 6-pin mini-DIN connector. It is compatible with all IBM PC-AT compatible keyboards. The keyboard is only recognized at power-up.

The Keyboard interface is not supported by CoDeSys in the initial release of these SMLC models.



Figure 5, Keyboard Connector (J12) connector.

Pin	Signal	Description
1	KDAT	Bi-directional serial data line used to transfer data from or commands to the PC-AT keyboard.
2	MDAT	Bi-directional serial data line used to transfer data from or commands to the PS/2 mouse.
3	GND	Ground
4	VCC	Power
5	KCLK	Bi-directional clock signal used to strobe data/commands from/to the PC-AT keyboard.
6	MCLK	Bi-directional clock signal used to strobe data/commands from/to the PS/2 mouse.

Table 2, Keyboard/Mouse Connector (J12) pin-out.

J13 – Digital I/O Connector

The SMLC includes 8 digital inputs and 8 digital outputs via a 25 pin D-Sub female connector (J13). These I/O points are optically coupled and require an external voltage source via connector J18.

Pin	Description
1	Chassis Frame
2	Digital Input 1
3	Digital Input 2
4	Digital Input 3
5	Digital Input 4
6	Digital Input 5
7	Digital Input 6
8	Digital Input 7
9	Digital Input 8
10	Digital Output 2
11	Digital Output 4
12	Digital Output 6
13	Digital Output 8
14	Ground
15	Ground
16	Ground
17	Ground
18	Ground
19	Ground
20	Ground
21	Ground
22	Digital Output 1
23	Digital Output 3
24	Digital Output 5
25	Digital Output 7

Table 3, Digital I/O connector (J13) pin-out.




Figure 6, Schematic of Discrete Inputs IN1'-IN8'




Figure 7, *Schematic of Discrete Outputs OUT1'-OUT8'*

J14 – USB Port
J15 – USB Port

The USB ports are not supported by CoDeSys in the initial release of these SMLC models.

J16 – Ethernet Port EN1
J17 – Ethernet Port EN0

The Ethernet interface ports use an industry standard Intel 82551ER 10/100Base-Tx Ethernet chip (except the Model 160 port EN1 which is an Intel 82541 1000Base-T Ethernet chip). It can be used for networking with WAGO I/O, a MODBUS/TCP based HMI package or communications with the CoDeSys IDE or OPC Server.

Figure 8, SMLC - Ethernet Connector (J16 & J17) connector

Pin	Signal	Description
8	NC	NC = No Connection
7	NC	
6	RXD-	Ethernet 10/100Base-Tx differential receiver inputs.
5	NC	
4	NC	
3	RXD+	Ethernet 10/100Base-Tx differential receiver inputs.
2	TXD-	Ethernet 10/100Base-Tx differential transmitter outputs.
1	TXD+	Ethernet 10/100Base-Tx differential transmitter outputs.

Table 4, Ethernet Port (J16 & J17) pin-out.

Ethernet Cables & Accessories

EI8-10T	Ethernet Hub, 10BASE-T, 8 port, 24 VDC input, rail mount
405TX	Ethernet Switch, 10BASE-T, 5 port, 24 VDC input, rail mount
CBL-ENET/3	Cable, Ethernet, RJ45, 3 ft.
CBL-ENET/7	Cable, Ethernet, RJ45, 7 ft.
CBL-ENET/10	Cable, Ethernet, RJ45, 10 ft.
CBL-ENET/25	Cable, Ethernet, RJ45, 25 ft.
CBL-ENET/50	Cable, Ethernet, RJ45, 50 ft.
CBL-ENET/75	Cable, Ethernet, RJ45, 75 ft.
CBL-ENET/100	Cable, Ethernet, RJ45, 100 ft.
<p>DO NOT USE CROSSOVER CABLES WITH A HUB. Crossover cables are used for connection only two devices together. Example: SMLC to WAGO I/O without a hub.</p>	
CBL-ENETX/3	Cable, Ethernet crossover , RJ45, 3 ft.
CBL-ENETX/7	Cable, Ethernet crossover , RJ45, 7 ft.
CBL-ENETX/10	Cable, Ethernet crossover , RJ45, 10 ft.
CBL-ENETX/25	Cable, Ethernet crossover , RJ45, 25 ft.

Table 5, Ethernet Cables & Accessories part numbers.

J18 – Analog I/O Connector

The SMLC includes a 14-bit analog input and a 14-bit analog output on connector J18. This connector is also the location for supplying the power for the digital inputs and outputs. The presence of the I/O supply voltage is indicated by the 24V LED on the front of the SMLC.

Pin	Signal	Description
1	AOUT	Analog output
2	AGND	Analog ground
3	AIN	Analog input
4		Chassis ground
5	24V	I/O supply voltage +
6	R24	I/O supply voltage -


Table 6, Analog I/O connector (J18) pin-out.

J19 – VGA Connector

The VGA connector is capable of supporting a wide range of flat panel, CRT and LCD displays. There is no CoDeSys support for the VGA display in the initial release of these SMLC models.

***NOTE:** Beginning with SMLC firmware revision 2.0.0 the IP addresses assigned to the Ethernet ports are printed to the VGA port at power-up. If the IP address assignments of the Ethernet ports is unknown they may be determined by connecting a standard VGA monitor to this port and power cycling the SMLC.*

Figure 9, SMLC - CRT Connector (J19) connector



Pin	Signal	Description
1	RED	Analog output carrying the red color signal to the CRT. For 75 ohm cable impedance.
2	GREEN	Analog output carrying the green color signal to the CRT. For 75 ohm cable impedance.
3	BLUE	Analog output carrying the blue color signal to the CRT. For 75 ohm cable impedance.
4	NC	No Connection
5	DIG-GND	Ground reference for HSYNC and VSYNC.
6	ANA-GND	Ground reference for RED, GREEN, and BLUE
7	ANA-GND	
8	ANA-GND	
9	NC	No Connection
10	DIG-GND	Ground reference for HSYNC and VSYNC.
11	NC	
12	DDCDAT	Display Data Channel Data. Used as data signal to/from monitors with DDC interface.
13	HSYNC	CRT horizontal synchronization output.
14	VSYNC	CRT vertical synchronization output.
15	DDCCLK	Display Data Channel Clock. Used as clock signal to/from monitors with DDC interface.


Table 7, CRT Connector (J19) pin-out

J20 – Development Serial Port COM1 - RS232

SMLC programming, system development, and system monitoring are accomplished by using an IBM-PC or compatible PC attached to the RS-232 Development Serial Port connector (J20), which is located on the front of the SMLC. The Development Serial Port is an asynchronous RS-232 device. It is handled internally by a 16C550 compatible serial communications controller, and interfaced through a DB9 connector. Connection between the development computer and SMLC Development Serial Port can be made while power is applied to the SMLC.

ORMEC can provide a coil-cord style communication cable (part number CBL-CDS-SER/10) for the Development Serial Port which are compatible with an IBM PC (DB9) style serial connector.

Figure 10, RS-232 Serial Port Connector (J20,J21,J22,J23) Pinout



Pin	Signal	Description
1	DCD	Data Carrier Detect. This signal indicates that the modem or data set has detected the data carrier.
2	RxD	Serial input. This signal receives serial data from the communication link.
3	TxD	Serial output. This signal sends serial data to the communication link. The signal is set to a marking state on hardware reset when the transmitter is empty or when loop mode operation is initiated.
4	DTR	Data Terminal Ready. This signal indicates to the modem or data set that the on-board UART is ready to establish a communication link.
5	GND	Ground
6	DSR	Data Set Ready. This signal indicates that the modem or data set is ready to establish a communication link.
7	RTS	Request To Send. This signal indicates to the modem or data set that the on-board UART is ready to exchange data.
8	CTS	Clear To Send. This signal indicates that the modem or data set is ready to exchange data.
9	RI	Ring Indicator. This signal indicates that the modem has received a telephone ring signal.

Table 8, RS-232 Serial Port Connector (J20,J21,J22,J23) pin-out.

J21 – SMLC HMI Serial Port COM2 - RS232

The SMLC HMI serial port J21 uses a DB9 connector that provides access to asynchronous serial 232 communications. This port is commonly used to interface to the ORMEC HMI flat-panel touch-screen, but any serial MODBUS protocol master device can be used. It can alternately be used for general purpose serial communications with terminals, computers or programmable controllers by using the CoDeSys Library SysLibCom.lib.

Connections to the SMLC HMI Serial Port is made through connector J21, which is located on the lower left side of the SMLC. The pin-out of the SMLC HMI Serial Port is shown in **Figure 10,** RS-232 Serial Port Connector (J20,J21,J22,J23) Pinout.

J22 – SMLC User Serial Ports COM3 - RS232

J23 – SMLC User Serial Ports COM4 - RS232 (Model 160 only)

The SMLC User serial ports use a DB9 connector that provides access to asynchronous serial RS-232 communications. The ports can be used for general purpose serial communications with terminals, computers or programmable controllers by using the CoDeSys Library SysLibCom.lib.

Connections to the SMLC User Serial Ports are made through connector J22 & J23, which are located on the lower left side of the SMLC. The pin-out of the SMLC User serial ports is shown in **Figure 10**, RS-232 Serial Port Connector (J20,J21,J22,J23) Pinout. COM4 (J23) is only available on the Model 160

TB1– Input AC Power Connector

ServoWire Motion & Logic Controller Manual operate on either 115 VAC or 230 VAC power (50/60 Hz), without the need to configure the unit for the desired input power.

The SMLC power connector is pluggable. Screw type terminals accept 14 AWG gauge wire.

Pin	Description
1	L1
2	Chassis ground
3	L2

Table 9, Power connector (TB1) pinout.

LEDs

The functioning of the LEDs is defined in section 6.1. The state of the LEDs is indeterminate after a power cycle or reset. When the SMLC firmware has finished loading the Watchdog OK LED will start flashing. This indicates that the boot process has completed.

Reset Pushbutton

The reset pushbutton is recessed on the front panel of the SMLC. Pressing the reset pushbutton will reset the processor causing motors to be disabled and the SMLC to reboot. Resetting is a satisfactory alternative to power cycling the SMLC after performing an SMLC firmware upgrade.

System Card

The System Card is a Compact Flash format storage device that contains the operating system, SMLC firmware, SMLC settings such as Ethernet IP addresses as well as the user application and data. The system card may be transferred from SMLC to SMLC or even pre-programmed and sent to a remote location.

Chapter 5

System Power Wiring & Interlocks

5 System Power Wiring & Interlocks

The SMLC provides integrated emergency stop and fault interlocks **through the servodrives**. System wiring diagrams for standard ORMEC servodrives, which include the recommended safety and fault interlocks for a typical system, are provided in the Appendix B, page # 56. The primary features of these system-wiring diagrams are:

- The Main Power Contactor switches servomotor power, called Main Power.
- For the *Main Power Contactor* to be enabled, both the ServoWire Drive *E-Stop/Quick Stop* input and the Drive Ready output must be closed.
- For the *Drive Ready* output on the servodrive to be closed, five conditions must be satisfied:
 1. There must be no SMLC diagnostic faults, including power-up diagnostics.
 2. There must be power (+5 to +24 referenced to RTN) applied to the drives V+S input and RTN must be connected to V-S.
 3. There must be current flow from the drives E-Stop/Quick-Stop input to V-S.
 4. There must be no drive faults from any standby or active servodrive and no open encoder signal wires on axes in pacer, standby, or active mode.
 5. Bus power must be applied to the drive.

There are many acceptable variations of these System Wiring Diagrams. If using a variation, it should incorporate the primary features as described above and as shown in the Appendix. Contact the ORMEC Service Department with any questions you may have in this area.

Emergency-Stop / Quick-Stop and Drive Ready Configuration

Located on the ServoWire drive is an Emergency-Stop / Quick -Stop input and Drive Ready output, allowing fail-safe control.

Emergency Stop Input:

A discrete input can be configured to operate as Emergency Stop input. When unasserted, this input causes the servo drive to generate a drive fault and disable output power to the motor, as well as generating an **OP_FAULT** condition in the application program.

Quick Stop Input:

A discrete input can be configured to operate as Quick Stop input. Unasserting the input in this mode generates an **OP_ALARM** condition in the application program and has the effects indicated below, which are dependent on the axis mode of operation (torque, velocity or position).

- **Torque mode** - Generates an **OP_ALARM** condition in the application program, output remains enabled and the drive continues to receive torque commands. This allows the application program to decelerate the load under control.
- **Velocity / Position mode** - Generates an **OP_ALARM** condition in the application program, output remains enabled, zero speed is commanded. Commanding zero speed may result in commanded current to bring the motor to a stop.

WARNING: The SMLC and servodrives must be configured in ServoWire Pro for E-Stop / Quick-Stop operation.

ServoWire Pro Drive Properties

Right mouse click on the ServoWire Pro “Drive network \ Drive Icon” to display the drive properties form.




Figure 11, ServoWire Pro Drive Properties

Selecting the ServoWire drive input behavior

ServoWire Pro, "Drive Properties / Inputs" Setup screen, allows a user-configurable input to be used to indicate when the drive is operating normally, without faults. This input is intended for use in the system E-Stop interlock circuit.




Figure 12, ServoWire Pro E-Stop / Quick Stop configuration

Note: SDM Drive E-Stop/Quick Stop configuration is identical to SMM

Selecting the ServoWire drive output behavior

ServoWire Pro, "Drive Properties / Outputs" Setup screen, allows a user-configurable output to indicate when the drive is operating normally, without faults and the main bus is charged. This output is intended for use in the system Emergency-Stop interlock circuit.





Figure 13, ServoWire Pro Drive Ready configuration

Note: SDM Drive Ready configuration is identical to SMM

5.1 ServoWire Drive Input / Output

SDM Servodrive I/O

	<p>3 Discrete Inputs: IN1 or Hardware Travel Limit Forward IN2 or Hardware Travel Limit Reverse IN3 or E-Stop / Quick Stop</p> <p>1 Discrete Bi-directional I/O: IN4 or [OUT4 or Drive Ready] *See note.</p>	Drive I/O Connections																																												
	<p>4 Discrete Outputs: OUT1 OUT2 OUT3 or Brake Control OUT5 or ZREF Feedback</p>	TB4		TB5																																										
	<p>2 Sensors Inputs: ASEN, BSEN</p>	<table border="1"> <tr><td>1</td><td>Shield</td></tr> <tr><td>2</td><td>ASEN</td></tr> <tr><td>3</td><td>BSEN</td></tr> <tr><td>4</td><td>V+S</td></tr> <tr><td>5</td><td>V-S</td></tr> <tr><td colspan="2" style="text-align: center;">TB3</td></tr> <tr><td>1</td><td>AIN</td></tr> <tr><td>2</td><td>AGND</td></tr> <tr><td>3</td><td>AOUT</td></tr> <tr><td>4</td><td>Shield</td></tr> </table>	1	Shield	2	ASEN	3	BSEN	4	V+S	5	V-S	TB3		1	AIN	2	AGND	3	AOUT	4	Shield	<table border="1"> <tr><td>1</td><td>V+S</td></tr> <tr><td>2</td><td>V-S</td></tr> <tr><td>3</td><td>IN1/HTLF</td></tr> <tr><td>4</td><td>IN2/HTLR</td></tr> <tr><td>5</td><td>IN3</td></tr> <tr><td>6</td><td>IN4/OUT4</td></tr> <tr><td>7</td><td>Out4 Return</td></tr> <tr><td>8</td><td>Shield</td></tr> <tr><td>9</td><td>OUT1</td></tr> <tr><td>10</td><td>OUT2</td></tr> <tr><td>11</td><td>OUT3</td></tr> <tr><td>12</td><td>OUT5/ZREF</td></tr> </table>	1	V+S	2	V-S	3	IN1/HTLF	4	IN2/HTLR	5	IN3	6	IN4/OUT4	7	Out4 Return	8	Shield	9	OUT1	10	OUT2	11	OUT3	12
1	Shield																																													
2	ASEN																																													
3	BSEN																																													
4	V+S																																													
5	V-S																																													
TB3																																														
1	AIN																																													
2	AGND																																													
3	AOUT																																													
4	Shield																																													
1	V+S																																													
2	V-S																																													
3	IN1/HTLF																																													
4	IN2/HTLR																																													
5	IN3																																													
6	IN4/OUT4																																													
7	Out4 Return																																													
8	Shield																																													
9	OUT1																																													
10	OUT2																																													
11	OUT3																																													
12	OUT5/ZREF																																													

*** Note:**
 Input #4 is Bi-directional & shares the same pin with Output #4. If Output #4 is enabled, then Input #4 will read the state of Output #4.

Figure 14 SAC-SDM Servodrive I/O

SMM Servodrive I/O


	<p>3 Discrete Inputs: IN1 or Hardware Travel Limit Forward IN2 or Hardware Travel Limit Reverse IN3 or E-Stop / Quick Stop</p> <p>1 Discrete Bi-directional I/O: IN4 or [OUT4 or Drive Ready] *See note.</p>	<p>J3 SM Drive I/O Connections</p> <table border="1"> <tr> <td>1</td><td>ASEN</td><td>2</td><td>BSEN</td></tr> <tr> <td>3</td><td>V+S</td><td>4</td><td>V+S</td></tr> <tr> <td>5</td><td>V-S</td><td>6</td><td>V-S</td></tr> <tr> <td>7</td><td>Shield</td><td>8</td><td>Shield</td></tr> <tr> <td>9</td><td>IN1 / HTLF</td><td>10</td><td>OUT1</td></tr> <tr> <td>11</td><td>IN2 / HTLR</td><td>12</td><td>OUT2</td></tr> <tr> <td>13</td><td>IN3</td><td>14</td><td>OUT3</td></tr> <tr> <td>15</td><td>IN4 / OUT4</td><td>16</td><td>Output 4 Return</td></tr> <tr> <td>17</td><td>Shield</td><td>18</td><td>OUT5</td></tr> <tr> <td>19</td><td>V+S</td><td>20</td><td>V-S</td></tr> </table> <p>* Note: Input #4 is Bi-directional & shares the same pin with Output #4. If Output #4 is enabled, then Input #4 will read the state of Output #4.</p>	1	ASEN	2	BSEN	3	V+S	4	V+S	5	V-S	6	V-S	7	Shield	8	Shield	9	IN1 / HTLF	10	OUT1	11	IN2 / HTLR	12	OUT2	13	IN3	14	OUT3	15	IN4 / OUT4	16	Output 4 Return	17	Shield	18	OUT5	19	V+S	20	V-S
	1		ASEN	2	BSEN																																					
	3		V+S	4	V+S																																					
5	V-S	6	V-S																																							
7	Shield	8	Shield																																							
9	IN1 / HTLF	10	OUT1																																							
11	IN2 / HTLR	12	OUT2																																							
13	IN3	14	OUT3																																							
15	IN4 / OUT4	16	Output 4 Return																																							
17	Shield	18	OUT5																																							
19	V+S	20	V-S																																							
<p>4 Discrete Outputs: OUT1 OUT2 OUT3 or Brake Control</p> <p>OUT5 or ZREF Feedback</p>																																										
<p>2 Sensors Inputs: ASEN, BSEN</p>																																										

Figure 15 SAC-SMM Servodrive I/O

SWM Servodrive I/O


	<p>2 Discrete Inputs: IN1 or Hardware Travel Limit Forward IN2 or Hardware Travel Limit Reverse or E-Stop / Quick Stop</p>	<p>SW Drive I/O Connections</p> <table border="1"> <thead> <tr> <th colspan="2">TB1a</th> <th colspan="2">TB1b</th> </tr> </thead> <tbody> <tr> <td>1</td><td>ASEN</td> <td>1</td><td>Analog 1 Out</td> </tr> <tr> <td>2</td><td>BSEN</td> <td>2</td><td>Analog 2 Out</td> </tr> <tr> <td>3</td><td>CSEN</td> <td>3</td><td>Analog Gnd</td> </tr> <tr> <td>4</td><td>Shield</td> <td>4</td><td>Shield</td> </tr> <tr> <td>5</td><td>V+S</td> <td>5</td><td>ZREF Out</td> </tr> <tr> <td>6</td><td>V+S</td> <td>6</td><td>OUT1</td> </tr> <tr> <td>7</td><td>V-S</td> <td>7</td><td>OUT2</td> </tr> <tr> <td>8</td><td>V-S</td> <td>8</td><td>OUT3</td> </tr> <tr> <td>9</td><td>LR / IN2 E-Stop</td> <td>9</td><td>OUT4</td> </tr> <tr> <td>10</td><td>LF / IN1</td> <td>10</td><td>OUT5 / Drive Ready</td> </tr> <tr> <td>11</td><td>Delay</td> <td>11</td><td>OUT6 / Break</td> </tr> </tbody> </table>	TB1a		TB1b		1	ASEN	1	Analog 1 Out	2	BSEN	2	Analog 2 Out	3	CSEN	3	Analog Gnd	4	Shield	4	Shield	5	V+S	5	ZREF Out	6	V+S	6	OUT1	7	V-S	7	OUT2	8	V-S	8	OUT3	9	LR / IN2 E-Stop	9	OUT4	10	LF / IN1	10	OUT5 / Drive Ready	11	Delay	11	OUT6 / Break
	TB1a		TB1b																																															
	1		ASEN	1	Analog 1 Out																																													
	2		BSEN	2	Analog 2 Out																																													
3	CSEN	3	Analog Gnd																																															
4	Shield	4	Shield																																															
5	V+S	5	ZREF Out																																															
6	V+S	6	OUT1																																															
7	V-S	7	OUT2																																															
8	V-S	8	OUT3																																															
9	LR / IN2 E-Stop	9	OUT4																																															
10	LF / IN1	10	OUT5 / Drive Ready																																															
11	Delay	11	OUT6 / Break																																															
<p>6 Discrete Outputs: OUT1 OUT2 OUT3 OUT4 OUT5 or Drive Ready OUT6 or Brake Control</p>																																																		
<p>3 Sensors Inputs: ASEN, BSEN, CSEN</p>																																																		
<p>2 Analog Outputs: Analog 1 Out Analog 2 Out</p>																																																		

Figure 16 SAC-SWM Servodrive I/O

Chapter 6

System Operation

6 System Operation

6.1 SMLC Status LED's

A total of eight status LEDs are provided on the face of the SMLC for indicating system status.

Name	Color	Description
POWER	Green	There is 5V present on the main processor board
Disk	Yellow	The Compact Flash disk is being accessed
RUN	Green	The SMLC is in run mode.
FAULT	Red	Internal error. The SMLC must be power cycled to reset. A dump file will be generated and may be retrieved via ServoWire Pro's Dump utility. Contact ORMEC Service department for instructions.
Watchdog OK	Yellow	System Watchdog LED MUST BE FLASHING . This flashing yellow system Watchdog OK LED on the front of the controller will flash every second during normal operation. When CoDeSys is online with the SMLC this LED will flash twice a second. When CoDeSys is logged out the flashing will resume at once per second. If the LED stops flashing the SMLC operation is completely suspended and the Fault LED should come on. If you have disconnected CoDeSys and the LED is still flashing twice per second you will not be able to re-establish CoDeSys communications until you power cycle the SMLC.
USER	Yellow	Under application program control by MC UserLED.
24V	Green	The User supplied I/O voltage is present on J18.
SYSTEM	Yellow	SRAM Non-volatile memory batteries need to be replaced. Tested every 24 hours. The battery is not user replaceable. Contact ORMEC Service for repair.

Table 10, SMLC Status LED's

6.1.1 Power-up

ServoWire Motion & Logic Controller is a user-programmable device and operation is dependent on the ServoWire Pro configuration file & SMLC program present on the System Card.

Whenever AC power is applied to the SMLC, it executes its power-up sequence, which can last up to 30 seconds. When the Watchdog OK LED starts flashing at its once per second rate the power-up sequence is complete.

NOTE: Until the SMLC is initialized the state of the Status LED's on the SMLC do not properly indicate the system status.

6.2 SMLC Non-volatile memory

The CoDeSys Programming language supports non-volatile (NV) variables through the use of **RETAIN** and **PERSISTENT** keywords. Unlike normal CoDeSys variables, NV variable values are maintained through a loss of power or system reset, and are available to a user's application program when power is restored. 32 Kbytes of NV storage is available on the SMLC Models covered in this manual

Retain variables are identified by the keyword **RETAIN**. These variables maintain their value even after an uncontrolled shutdown of the controller as well as after a normal switch off and on of the controller. When the program is run again, the stored values will be processed further.

Persistent variables are identified by the keyword **PERSISTENT**. Unlike Retain variables, these variables retain their value after a re-download or 'Online' 'Reset', but not at switching off and on of the controller (i.e. not at the command 'Online' 'Reset'), because they are not saved in the "retain area".

To reset the non-volatile variables to 0 use the command 'Online' 'Reset (original)'. Note that this will delete your boot project as well.

See: CoDeSys Help for further details.

6.3 Specifications

CPU Processor types	Model: 30 – 650 MHz Celeron 80 – 933 MHz Pentium III 160 – 1.4 GHz Pentium M
Total controller memory ¹	128 M bytes DRAM
SMLC program memory ¹	128 M bytes Compact Flash
Non-volatile variable memory ¹	32 K bytes Battery Backed SRAM
Memory Cards	None

Table 11, SMLC Controller General Specifications

SMLC Mechanical and Environmental Specifications



Dimensions	Model 30 & 80: 9.0” High x 2.75” Wide x 7.23”Deep (228.6 H x 69.8 W x 183.6 D) Model 160: 9.0” High x 4.25” Wide x 7.23” Deep (228.6 H x 107.9 W x 183.6 D)
Weight	Model 30/80: 3.3lb Model 160: 3.5 lb
Operating Temperature	0 ~ 50C, (32~122 °F)
Storage Temperature	-25C to 70C (-13 °F to 158 °F)
Relative Humidity	10 ~ 95% @ 40'C, non-condensing
Mounting & Airflow	Mounting must be vertical; Airflow must be unrestricted.

Table 12, SMLC Controller Mechanical and Environmental Specifications

¹ Refer to the SMLC Memory chapter of for further information regarding memory utilization.

Input AC Power Ratings

ServoWire Motion & Logic Controller	115 VAC (90 - 127 VAC), 47 - 63 Hz - or - 230 VAC (190 - 253 VAC), 47 - 63 Hz The power supply is auto sensing
ServoWire SMM Drive Control Power	115 or 230 VAC, 50/60 Hz SAC-SMM203, 205, 210 & 217 20 W typical (45 W max.) SAC-SMM220 30 W typical (55 W max.)
Operator Display	24 VDC

Table 13, SMLC and Accessories Input Power

Battery Power Specifications

SMLC Main processor - BIOS	One - lithium Battery
SMLC Battery Backed SRAM	One - BR2032 lithium Battery (3 Volt, 190 mA Hr)
Data Retention	10 years of data retention powered. 1 year minimum, 5 year typical, unpowered.

Table 14, SMLC Battery Power

Digital I/O Power requirements

VIO+	4.5 volts to 27 volts
VIO-	not tied to SMLC ground

Table 15, Digital I/O Power requirements

Digital Input Specifications

Current to turn on	0.7ma minimum 7.0ma maximum
Common VIO+	inputs sink to VIO-
Voltage max	VIO+ + 5vdc

Table 16, Digital input specifications

Digital Output Specifications

Open collector outputs with a common VIO-.
Internal pullup on each output

Max sink current	33ma
low level voltage	1.2VDC
high level voltage	VIO+ - 0.5VDC
absolute maximum	27VDC

Table 17, Digital output specifications

Analog Input Specifications

12-bit resolution component. Return pin is shared with analog output. Note that analog ground is not isolated from the SMLC ground

Input range	+10VDC to -10VDC
--------------------	------------------

Table 18, Analog input specifications

Analog Output Specifications

12-bit resolution component. Return pin is shared with analog input. Note that the analog ground is not isolated from the SMLC ground

Output range	+10VDC to -10VDC
Max output rate	5kHz
Output settling time	20usec
Max output current	10mA

Table 19, Analog output specifications

Development port COM1 Specifications

Connector	9 pin Male D Sub
Standards	EIA RS-232C
Default Config	8 data bits 1 stop bit no parity
Baud Rate	115.2K

Table 20, SMLC Development Serial Port

HMI Serial Port COM2 Specifications

Connector	9 pin Male D Sub
Standards	EIA RS-232
Default Config.	8 data bits 1 stop bits no parity
Baud Rates	115.2K, 57.6K, 38.4K, 19.2K (Default), 9600, 4800, 2400, 1200

Table 21, SMLC HMI Serial Ports

Serial Port COM3 and COM4 (Model 160 only) Specifications

Connector	9 pin Male D Sub
Standards	EIA RS-232
Default Config.	8 data bits 1 stop bits no parity
Baud Rates	115.2K, 57.6K, 38.4K, 19.2K, 9600, 4800, 2400, 1200

Table 22, SMLC Serial Ports COM3 & COM4

Chapter 7


WAGO Installation & Operation

7 WAGO Installation & Operation

General Purpose I/O

General-purpose I/O options are supported using FireWire, PROFIBUS DP or MODBUS/TCP I/O from WAGO (750 Series). Depending on your application’s speed, distance, wiring and budget requirements, you can select a technology that matches your system requirements.

The I/O system offers a Fieldbus independent node design, even though the Fieldbus couplers utilizing different protocols. Cage clamp technology helps reduce installation time and provides gas-tight I/O connections that are maintenance-free and resistant to vibration.



The WAGO System consists of three components:

1. One Fieldbus Coupler (Left end)
2. A number of I/O modules (Middle)
3. One End Module (Right end).

The WAGO-ETH-KIT (fieldbus coupler) is a 10baseT, 64 I/O module (256 points max) that supports a wide selection of I/O module types and includes the end module. Your system can mix and match a wide variety of I/O modules including digital I/O with up to eight points each and analog I/O in several resolutions and signal types. A selection of specialty modules are also available – including a selection of thermocouples that can be used to implement PID control, up/down counters and an incremental encoder interface

7.1 WAGO Installation

Setting the WAGO IP Address

The WAGO fieldbus coupler needs to be assigned an IP address. WAGO’s BootP Server is used to assign an IP Address to the hardware MAC (Media Access Code) ID of the fieldbus coupler.

- Launch the WAGO BootP server.




Figure 17, WAGO Launch BootP server




Figure 18, WAGO Launch Notepad

- The file “**BootPtab.txt**” needs to be modified.




Figure 19, WAGO edit BootPtab.txt.

The file “**BootPtab.txt**” has many lines that are commented by the “#” (pound symbol). Any line without a # will be processed so be careful when editing this file.

Look at the first line (near the bottom of the file) that does not have a pound symbol. (#)

KeinProxy:ht=1:ha=0030DE000002:ip=10.1.254.202:

- **KeinProx** - is a label. German meaning “Node Name”. It may be changed to any label or descriptor you like to identify the WAGO Ethernet I/O hardware.

Example **MyWAGOconfig**:

- **ht** = hardware type.
- **ha** = is short for **H**ardware **A**ddress, also known as the MAC ID. It needs to match the MAC ID number that is located on the right side of the field coupler.
Example **ha=0030DE000002**:

- **ip** = is short for **I**nternet **P**rotocol, the WAGO node address.

Example **ip=192.168.0.123**:

MyWAGOconfig:ht=1:ha=0030DE000002:ip=192.168.0.123:

Look at the bottom (last) line in the file. This is a **second example** that demonstrates how to add the gateway address. If a gateway address is not going to be used, comment out this line by adding a #. Most applications typically do not use the gateway.

hamburg:ht=1:ha=0030DE000003:ip=10.1.254.203:T3=0A.01.FE.01:

- Now save the WAGO configuration file **BootPtab.txt** by clicking on the notepad - File/Save. Close the notepad editor.




Figure 20, WAGO Start BootP Server

- Now click on the start tab to display status messages.
- Turn the power off on the WAGO fieldbus coupler and wait for 5 seconds.

Now turn the power back on the WAGO fieldbus coupler. You should see additional status messages scrolling down the BootP Server screen.

Verify the status information displayed:

- Packets were received from an IP Address.
- The Ethernet Address is the same as the MAC ID of the Fieldbus coupler.
- The KeinProxy, or node identifier, and IP Address match what was entered in the text file using Notepad.

Verify the WAGO buscoupler or PFC is operating correctly. Its diagnostic LED's should be illuminated as follows:

On	Green
Link	Green
TxD/RxD	Flash as data is Sent/Received
Error	Should not be illuminated
I/O	Green

Your WAGO Fieldbus coupler is now ready for communications on an Ethernet network.

7.2 WAGO Part List

WAGO-ETH-KIT	Ethernet Fieldbus Coupler Kit, 10baseT, 64 I/O modules for 256 ins & 256 outs max. (incl. one End Module and two 10 mm End Stops) NOTE 1: WAGO Fieldbus couplers supply a limited amount of 24 VDC power to the I/O modules, which may not be sufficient for the application. A Power Supply and Supply Module may be required. Refer to the WAGO Ethernet or PROFIBUS I&O Manual or the WAGO Web Site for further information.
WAGO-750-342	Ethernet Fieldbus Coupler, 10BaseT, 64 I/O modules for 256 inputs & 256 outputs max.

WAGO Digital Input Modules

WAGO-750-400	2-Ch DC Input, Sourcing (high-side switch), 24 VDC, 3.0 msec filter
WAGO-750-401	2-Ch DC Input, Sourcing (high-side switch), 24 VDC, 0.2 msec filter, high spd
WAGO-750-410	2-Ch DC Input, Sourcing (high-side switch), 24 VDC, 3.msec filter, 2-wire prox. switch
WAGO-750-411	2-Ch DC Input, Sourcing (high-side switch), 24 VDC, 0.msec filter, high spd, 2-wire prox. Switch.
WAGO-750-418	2-Ch DC Input, Sourcing (high-side switch), 24 VDC, 3.0 msec filter, diagnostics w/ ack
WAGO-750-419	2-Ch DC Input, Sourcing (high-side switch), 24 VDC, 3.0 msec filter, diagnostics
WAGO-750-412	2-Ch DC Input, Sourcing (high-side switch), 48 VDC, 3.0 msec filter (see note 2)
WAGO-750-424	2-Ch DC Input, Sourcing (high-side switch), 24 VDC, Intruder Detection
WAGO-750-402	4-Ch DC Input, Sourcing (high-side switch), 24 VDC, 3.0 msec filter
WAGO-750-403	4-Ch DC Input, Sourcing (high-side switch), 24 VDC, 0.2 msec filter, high spd
WAGO-750-408	4-Ch DC Input, Sinking (low-side switch), 24 VDC, 3.0 msec filter
WAGO-750-409	4-Ch DC Input, Sinking (low-side switch), 24 VDC, 0.2 msec filter, high spd
WAGO-750-414	4-Ch DC Input, Sourcing (high-side switch), 5 VDC, 0.2 msec filter, high spd (see note 2)
WAGO-750-422	4-Ch DC Input, Sourcing (high-side switch), 24 VDC, 1.0 msec filter, w/ 10 msec ext.
WAGO-750-415	4-Ch AC/DC Input, 24VAC/VDC, 20 msec filter, 2-wire connection (see note 2)
WAGO-750-423	4-Ch AC/DC Input, Sourcing (high-side switch), 24 VAC/VDC, 50 msec filter, w/ power jumper contacts (supply module req'd for 24 VAC operation) (see note 2)
WAGO-750-430	8-Ch DC Input, Sourcing (high-side switch), 24 VDC, 3.0 msec filter
WAGO-750-431	8-Ch DC Input, Sourcing (high-side switch), 24 VDC, 0.2 msec filter, high spd
WAGO-750-435	1-Ch DC Input, 24 VDC, 3.0 msec filter, NAMUR
WAGO-750-425	2-Ch DC Input, 24VDC, 3.0 msec filter, NAMUR
WAGO-750-405	2-Ch AC Input, 230VAC (see note 2)
WAGO-750-406	2-Ch AC Input, 120VAC (see note 2)

WAGO Digital Output Modules

WAGO-750-501	2-Ch DC Output, Sourcing (high-side switch), 24 VDC, 0.5 A
WAGO-750-502	2-Ch DC Output, Sourcing (high-side switch), 24 VDC, 2.0 A
WAGO-750-504	4-Ch DC Output, Sourcing (high-side switch), 24 VDC, 0.5 A
WAGO-750-506	2-Ch DC Output, Sourcing (high-side switch), 24 VDC, 0.5A, w/ diagnostics
WAGO-750-507	2-Ch DC Output, Sourcing (high-side switch), 24 VDC, 2.0 A, w/ diagnostics
WAGO-750-509	2-Ch AC/DC Output, SSR, 230 VAC/VDC, 300 mA (see note 2)
WAGO-750-512	2-Ch Relay Output, normally open, 230 VAC/30 VDC, 2.0 A (see note 2)
WAGO-750-513	2-Ch AC/DC Output, Isolated relay, 250 VAC/30VDC, 2.0A (see note 2)
WAGO-750-514	2-Ch Relay Output, changeover contacts (SPDT), 125 VDC/30 VDC, 0.5 A (see note 2)
WAGO-750-516	4-Ch DC Output, Sinking (low-side switch), 24 VDC, 0.5 A
WAGO-750-517	2-Ch Relay Output, changeover contacts (SPDT), 230 VDC/300 VDC, 1.0 A (see note 2)
WAGO-750-519	4-Ch DC Output, Sourcing (high-side switch), 5 VDC, 20 mA (see note 2)
WAGO-750-522	2-Ch AC Output, opto isolated, 35-230 VAC, 0.5 A, 3.0A for 30 sec once per hour (note2)
WAGO-750-523	1-Ch AC Output, opto isolated, 230 VAC, 16A, auto/manual operation
WAGO-750-530	8-Ch DC Output, Sourcing (high-side switch), 24 VDC, 0.5A
WAGO-750-535	2-Ch DC Output, Sourcing (high-side switch), 24 VDC Eex I

WAGO Analog Input Modules

WAGO-750-465	2-Ch Analog Input, 0-20 mA, 12-bit, single-ended	
WAGO-750-453	4-Ch Analog Input, 0-20 mA, 12-bit, single-ended	
WAGO-750-452	2-Ch Analog Input, 0-20 mA, 12-bit, differential	(see note 3)
WAGO-750-480	2-Ch Analog Input, 0-20 mA, 13-bit, differential	(see note 3)
WAGO-750-472	2-Ch Analog Input, 0-20 mA, 16-bit, single-ended	
WAGO-750-472/005-000	2-Ch Analog Input, 0-20 mA, 16-bit, single-ended, 60 Hz	
WAGO-750-466	2-Ch Analog Input, 4-20 mA, 12-bit, single-ended	
WAGO-750-455	4-Ch Analog Input, 4-20 mA, 12-bit, single-ended	
WAGO-750-485	2-Ch Analog Input, 4-20 mA, 12-bit single-ended, explosion protection	
WAGO-750-454	2-Ch Analog Input, 4-20 mA, 12-bit, differential	(see note 3)
WAGO-750-492	2-Ch Analog Input, 4-20 mA, 12-bit, differential, isolated	(see note 3)
WAGO-750-474	2-Ch Analog Input, 4-20 mA, 16-bit, single-ended	
WAGO-750-474/005-000	2-Ch Analog Input, 4-20 mA, 16-bit, single-ended, 60 Hz	
WAGO-750-456	2-Ch Analog Input, +/-10 V, 12-bit, differential	(see note 3)
WAGO-750-457	4-Ch Analog Input, +/-10 V, 12-bit, single-ended	
WAGO-750-479	2-Ch Analog Input, +/-10 V, 14-bit, differential	(see note 3)
WAGO-750-476	2-Ch Analog Input, +/-10 V, 16-bit, single-ended	
WAGO-750-467	2-Ch Analog Input, 0-10 V, 12-bit, single-ended	(see note 3)
WAGO-750-459	4-Ch Analog Input, 0-10 V, 12-bit, single-ended	
WAGO-750-468	4-Ch Analog Input, 0-10 V, 12-bit, single-ended	(see note 3)
WAGO-750-478	2-Ch Analog Input, 0-10 V, 16-bit, single-ended	
WAGO-750-460	4-Ch Analog Input for RTD, Pt100 resistance sensors	(see note 3)
WAGO-750-483	2-Ch Analog Input, 0-30 V 14-bit, differential	
WAGO-750-469	2-Ch Analog Input for Thermocouple, Type K, w/ diagnostics	(see note 3)
WAGO-750-469/000-001	2-Ch Analog Input for Thermocouple, Type S, w/ diagnostics	(see note 3)
WAGO-750-469/000-002	2-Ch Analog Input for Thermocouple, Type T, w/ diagnostics	(see note 3)
WAGO-750-469/000-003	2-Ch Analog Input for Thermocouple, +/-120 mV, w/ diagnostics	(see note 3)
WAGO-750-469/000-006	2-Ch Analog Input for Thermocouple, Type J, w/ diagnostics	(see note 3)
WAGO-750-469/000-008	2-Ch Analog Input for Thermocouple, Type E, w/ diagnostics	(see note 3)
WAGO-750-469/000-012	2-Ch Analog Input for Thermocouple, Type L, w/ diagnostics	(see note 3)
WAGO-750-461	2-Ch Analog Input for RTD, Pt100 resistance sensors	(see note 3)
WAGO-750-461/000-003	2-Ch Analog Input for RTD, Pt1000 resistance sensors	(see note 3)
WAGO-750-461/000-004	2-Ch Analog Input for RTD, Ni100 resistance sensors	(see note 3)
WAGO-750-461/000-005	2-Ch Analog Input for RTD, Ni1000 resistance sensors	(see note 3)
WAGO-750-461/000-002	2-Ch Analog Input for RTD, Resistor measurement, 10 - 1.2k ohms	(see note 3)
WAGO-750-461/000-007	2-Ch Analog Input for RTD, Resistor measurement, 10 - 5.0k ohms	(see note 3)
WAGO-750-491	1-Ch Analog Input for Resistor Bridges, 16-bits, 250 msec conversion time	(see note 3)
WAGO-750-491/000-001	1-Ch Analog Input for Resistor Bridges, 16-bits, 65 msec conversion time	(see note 3)

WAGO Analog Output Modules

WAGO-750-552	2-Ch Analog Output, 0-20 mA, 12-bit	
WAGO-750-585	2-Ch Analog Output, 0-20 mA, 12-bit, explosion protection	
WAGO-750-554	2-Ch Analog Output, 4-20 mA, 12-bit	
WAGO-750-556	2-Ch Analog Output, +/-10 V, 12-bit	(see note 3)
WAGO-750-557	4-Ch Analog Output, +/-10 V, 12-bit	
WAGO-750-550	2-Ch Analog Output, 0-10 V, 12-bit	(see note 3)
WAGO-750-559	4-Ch Analog Output, 0-10 V, 12-bit	

WAGO Specialty Modules

WAGO-750-404	1-Ch Up/Down Counter, 24 VDC, 32-bit, 100 kHz
WAGO-750-638	2-Ch Up/Down Counter, 24 VDC, 16-bit, 500 Hz
WAGO-750-511	2-Ch PWM Output, 24 VDC, 0.1A, 10-bit, 250 Hz, configurable duty cycle
WAGO-750-630/000-013	SSI Transmitter Interface, 29-bit, 125 kHz, binary
WAGO-750-630/000-008	SSI Transmitter Interface, 25 bit, 125 kHz, graycode
WAGO-750-630/000-011	SSI Transmitter Interface, 25-bit, 125 kHz, binary
WAGO-750-630/000-006	SSI Transmitter Interface, 24-bit, 250 kHz, graycode
WAGO-750-630/000-002	SSI Transmitter Interface, 24-bit, 250 kHz, binary
WAGO-750-630	SSI Transmitter Interface, 24-bit, 125 kHz, graycode
WAGO-750-630/000-004	SSI Transmitter Interface, 24-bit, 125 kHz, graycode w/ status
WAGO-750-630/000-001	SSI Transmitter Interface, 24-bit, 125 kHz, binary
WAGO-750-630/000-007	SSI Transmitter Interface, 24-bit, 83 kHz, graycode w/ status
WAGO-750-630/000-005	SSI Transmitter Interface, 15-bit, 125 kHz, graycode w/ status
WAGO-750-630/000-009	SSI Transmitter Interface, 13-bit, 250 kHz, binary
WAGO-750-630/000-012	SSI Transmitter Interface, 13-bit, 125 kHz, graycode
WAGO-750-631	Incremental Encoder Interface, 16-bit pos capture, 5 VDC edr power output (note 2)
WAGO-750-637	Incremental Encoder Interface, 32-bit pos capture, pos compare, 5 VDC edr power output (see note 2)
WAGO-750-635	Digital Impulse Interface, for magnetostrictive distance measurement sensors

WAGO Power Supplies and Accessories

WAGO-787-602	Power Supply 1.3A, 24 VDC output
WAGO-787-612	Power Supply 2.5A, 24 VDC output
WAGO-787-622	Power Supply 5.0A, 24 VDC output
WAGO-787-632	Power Supply 10A, 24 VDC output
WAGO-787-640	Power Supply 10A, 24 VDC output, 3-phase 230 VAC input
WAGO-750-601	Supply module with fuse, 24 VDC
WAGO-750-612	Supply module, 0 – 230 AC/DC (incl. 5 VDC modules)
WAGO-750-602	Supply module, 24 VDC
WAGO-750-615	Supply module with fuse, 120 VAC
WAGO-750-609	Supply module with fuse, 230 VAC
WAGO-750-622	Binary Spacer Module
WAGO-750-600	End Module
WAGO-249-117	End Stop
WAGO-247-PWR	Power and Ground Label Strip Pack blue “0V”, blue “-”, red “24V”, red “+”, light green ground symbol, light green “PE”, 100 each
WAGO-247-513/522	I/O Point Numbering Label Strip Pack, digits 00-99, 10 each

NOTE 2: Any WAGO Digital I/O modules operating at voltages other than 24 VDC require a Power Supply and Supply Module with the appropriate voltage rating for input power and isolation. Refer to the WAGO Ethernet or PROFIBUS I&O Manual or the WAGO Web Site for further information.

NOTE 3: WAGO Analog Output and 2-Channel AC/DC Output Isolated Relay modules do not pass the power supply on to other modules in the rack. A supply module will be required for any I/O modules to the right of an Analog Output or Isolated Relay module in a WAGO I/O system. Refer to the WAGO Ethernet or PROFIBUS I&O Manual or the WAGO Web Site for further information.

Chapter 8

Getting Started

8 Getting Started

8.1 Preparation for Test Run

For the test run, you need to:

1. Complete the appropriate System Wiring.
2. Create the configuration file “SwSetup” for your system by using ServoWire Pro.
3. Load the “SwSetup” file into the SMLC.

DO NOT connect the motor shafts to the driven machine until after the test run is complete!

Before the test run, do the following checks of the servomotor and ServoWire Motion & Logic Controller and their installation. Correct any problems before proceeding.

ServoWire Motion & Logic Controller Checklist

Verify that the power is fused properly and that the system power wiring and grounding are correct. See Appendix B of this manual, as well as the *Servo Drive Manual*.

- 1) If a "lot system test" (integrated system test) was performed at ORMEC, the servo system **must be** installed the same as they were at the ORMEC factory. Servodrives and servomotors must be connected in the same order because the servo loop configuration parameters are stored in the ServoWire Pro configuration file “*filename.SwSetup*” by *Axis-ID*.
- 2) Verify that the system grounding is correct. Refer to Appendix B and the appropriate *servodrive manual*.
- 3) Check for compatible voltage ratings on all servodrives obtaining control power from terminals “**r**” and “**t**” on the servo drive.
- 4) Verify that all wiring leads are firmly connected to their terminals.
- 5) Verify SMLC incoming line voltage (115 or 230 VAC) **CHECK POWER BEFORE APPLYING IT TO THE MOTION CONTROLLER!**

- 6) Attach an IBM-PC or compatible computer operating either the CoDeSys or ServoWire Pro communications utility to the SMLC Serial Development Port (J6) or Ethernet port (J5).

Servomotor Checklist

- 1) Verify proper motor mounting and that the **shaft is not connected to the machine.**
- 2) Verify that the encoder cables and motor cables are properly installed.
Note: ORMEC manufactured motor cables are color-coded.

Motor Cable Color	Servodrive Connection
RED	U
WHITE	V
BLACK	W
GREEN & SILVER	GROUND

- 3) Check that mounting bolts and nuts are tight.
- 4) Verify that motor shaft rotates freely by hand.
NOTE: If your motor has an integral fail-safe brake you must apply power to the brake coil in order to allow the motor shaft to rotate.
- 5) For motors with oil seals, (standard on IP-67 rated motors) the seals should be in good condition and properly lubricated.
- 6) Verify that the metal key is removed from the motor shaft keyway, or that it is securely taped down, for test.

Applying System Control Power

- 1) Refer to the section - Power-up (page 27) for further information regarding the SMLC power-up sequence.
- 2) After checking the items above, apply control power to the servodrives and toggle on the SMLC power switch located on the bottom of the SMLC chassis.
- 3) The SMLC will execute it's Power-up sequence as detailed in the section System Operation chapter (page 27).
- 4) After the Power-up sequence is complete, the Run light should be ON. At this point, the system is operating correctly and executing your application program.

8.2 Setting up SMLC Serial communications

ServoWire Pro uses Dial-Up Networking (DUN) to communicate with the SMLC Development port COM1 (J20). When your PC is properly configured and DUN is initialized (running), communications between ServoWire Pro and SMLC is possible. The connection address is 200.200.200.200. The Development Port communication rate is 115K Baud.

NOTE: You must configure your Network Connections in Windows before you can communicate with an SMLC. See: “**Network Setup Help**” included with ServoWire Pro software.

Initializing the Communications Connection

When ServoWire Pro needs to communicate with a SMLC, it checks to see if a DUN connection has been established. If no connection exists, the “Connect To” dialog is displayed, allowing you to initialize the SMLC connection. Thereafter, Windows handles all serial communications in the background.

Note: ServoWire Pro must know the correct Internet Protocol (IP) address of the SMLC it is connecting with. The factory address for the RS-232 Serial Port is “200.200.200.200”. This address refers to a Direct Cable Connection between ServoWire Pro and the SMLC Serial Port (J6).




Figure 21, ServoWire Pro IP Address

Disconnecting serial communications from SMLC and your PC.

Chose the Close Project command, in the ServoWire Pro File menu, if you want to reconnect to a different SMLC, or make changes to your network connections. To change your network connections, see Network Setup HELP.

Troubleshooting Connection Problems

If you are having difficulty in establishing communications with SMLC, see the ServoWire Pro Communications Troubleshooter.

8.3 SMLC Ethernet Configuration

It is strongly recommended that the Ethernet port be used for development with the SMLC because it supports a much faster communication rate of 10/100 M baud.

Default SMLC Ethernet Port Addressing

The SMLC assigns the **default IP Address of 192.168.0.253** to EN0 (J17).

The SMLC assigns the **default IP Address of 192.168.1.253** to EN1 (J16).

If you are going to use the default IP addresses you need to do nothing else.

Assigning SMLC Ethernet Port Addressing in ServoWire Pro.




Figure 22, ServoWire Pro Ethernet Ports IP Address

If you are adding the SMLC to an existing network, consult your Network Administrator to obtain an IP address and subnet mask that is compatible with your existing network.

Enter the desired Ethernet settings and Send them to the SMLC. You must then cycle the power on the SMLC for the new settings to take effect.

The SMLC Ethernet configuration can also be load/saved in a file. This is provided as convenient way to keep a record of Ethernet settings for different projects.

8.4 ServoWire Pro Development Software

Once power has been applied to the system, you should run ServoWire Pro to communicate with the SMLC unit. Consult the ServoWire Pro manual as appropriate for installation, startup, and communications details.

Test Running Your SMLC System

Once communications is established between the development computer and the SMLC unit, press the SwMonitor Icon to execute the SETUP program installed in the unit at the factory. SwTune allows a user to exercise an SMLC controller.

The SwTune program is menu-driven and will allow you to:

- 1) Home, Index one motor at a time and observe the motors response.
- 2) Interactively adjust servo loop parameters after the motors are connected to their respective loads, if required.

After setting up your system, you may save the system's loop configuration by using ServoWire Pro. When the system is configured for your application, you should proceed to develop your IEC 61131-3 application software.

Test Running Your SMLC System

Once communications is established between the development computer and the SMLC controller, ServoWire Pro can be used to configure the SMLC hardware.

The ServoWire Pro provides the ability to:

- Select the type of ServoWire drives the SMLC controller will use.
- Configure the ServoWire drive analog and digital I/O.
- Select the appropriate motors and drives and configure the Servodrive I/O using the Axis Settings configurator.

After the SMLC hardware has been configured for your application, the ServoWire Pro SwTune utility can be used to index and tune the axes.

The ServoWire Pro SwTune utility is a Windows based program that allows you to:

- Index all the motors, one at a time
- Interactively adjust servo loop parameters after the motors are connected to their respective loads, if required
- View graphical display of the commanded and actual motor velocity, commanded motor torque, and the position following error.

When the system hardware is configured for your application and the axes are tuned, you should proceed to develop your application software.

Chapter 9

Product History

9 Product History

9.1 Determining Hardware Revision Numbers

The hardware revision numbers for the SMLC motion controller is located on the left hand side of the unit.

9.2 SMLC Model 30, 80 and 160 History

Version 1.0a – September 2, 2005 - Initial release

Chapter 10

Maintenance & Troubleshooting

10 Maintenance & Troubleshooting

10.1 ORMEC Product Support

ORMEC Product Support relates to the functionality and proper operation of ORMEC supplied software and equipment

- Product Service is provided by the ORMEC Service Department. (585) 385-3520 Rochester New York, 14625.
- Assistance installing and upgrading ORMEC supplied development software (e.g. CoDeSys), and ServoWire Drive firmware, including necessary third-party supporting files (i.e. Microsoft Windows Dial-Up Networking used for serial communication).
- Assistance configuring ORMEC development software communications.
- Explanation/clarification of the functionality and proper operation of ORMEC supplied hardware and software, as provided in the various documentation available for those products (e.g. Windows Help, Installation & Operation Manuals, Tech and App Notes, etc.)
- Troubleshooting assistance for ORMEC supplied hardware and firmware to insure the proper operation of ORMEC supplied equipment. Assistance troubleshooting third-party equipment connected to ORMEC equipment is not included.
- Providing return authorization (RA) numbers and replacement units (if appropriate) for defective products.

Product Support

Phone and e-mail support, available from 8 AM to 5 PM EST. There is no charge for this service.

24-Hour Product Support

Phone support, available 24-hours a day, 7 days a week, 365 days per year. There is an additional charge for this service.

10.2 SMLC Troubleshooting

No LEDs Lit on SMLC

- 1) Verify that there is AC power to the. Verify that the AC voltage on the input power terminal block is the appropriate level (either 115 or 230 VAC).

SMLC Does Not Complete the Power Up Sequence

If the SMLC doesn't complete the power up sequence, gather the information listed below and call the ORMEC Service Department.

- 1) Look at the " System" LED. If illuminated (ON) the battery for non-volatile memory needs to be replaced.
- 2) SMLC model number, version number & serial number.
- 3) With the SMLC in the incomplete power up sequence, note the status of the LED's located on the front of the controller.
Power, Run, Fault, Watchdog OK, User, and System.
- 4) The SMLC version:
If you are able to communicate with the SMLC after resetting the unit or cycling power, the SMLC version can be determined by using ServoWire Pro's SwMonitor.

Chapter 11

Terms & Mnemonics

11 Terms & Mnemonics

There are a number of terms or "buzzwords" which are often used in the Motion Control Industry, some of which have very specific meanings in ORMEC's products and systems. This section attempts to define many of these terms used in this document which may be unfamiliar.

Absolute Encoder - a sensing device that provides the position of the motor shaft relative to a fixed reference point at power up without having move the motor shaft to determine that point. In the case of a multiple revolution absolute rotary encoder, the current position may be multiple turns away from the reference point.

Axis - In motion control, this term normally refers to one of the servomotors in the system, either by name or *Axis-ID* (Identification number) from 1 to 16. It is also used to refer to any *Master (Pacer) Encoders* in the system. Many ORMEC pre-defined variables in the SMLC are defined for each axis in the system and are therefore indexed by Axis-ID name.

CoDeSys – **C**ontroller **D**evelopment **S**ystem. The IEC-61131-3 runtime system developed by 3S Software used on the SMLC.

CoDeSys IDE – The CoDeSys Integrated Development Environment is the Win32 based application that allows you to develop, download and debug SMLC programs.

Current Source - The ability for a device to switch and provide current for a circuit.

Current Sink - The ability for a device to switch and accept the current in a circuit.

Electronic Gearing - A means of precisely coordinating the motion of a number of *servo axes* with a *pacemaker (master) axis*. The master axis can be an encoder or a servo axis.

Encoder - A digital position transducer used to determine the position of a motor, a rotating shaft on a machine or a linear position associated with a machine. It has two *quadrature* channels (A & B) which determine incremental movements and a single *encoder reference* channel (Z) which defines a unique position within its travel. Most, but not all, position encoders internally use optical gratings and sensors.

Encoder Zero Reference - A signal generated by the position *encoder* once per revolution, which may be used to determine the encoder's overall angular or linear orientation. Also sometimes called an *encoder marker pulse*.

Factory network adapters - A physical layer network interface which plugs into the SMLC and

contains a co-processor for performing factory network communications (e.g. PROFIBUS requires a factory network adapter card).

Follower - A servo axis, which is controlling its motion as a function of MotionDATA, generated by a *pacemaker* axis. Follower motions are generated with the MC_GEAR statement in the SMLC.

Home Position - A reference position for either a servo or an encoder *axis*.

Hardware Travel Limits HTL's - Inputs to ServoWire drive which must be asserted (sinking current), or disabled by software setting, for a servo axis to operate.

IEC-61131-3 - A global standard defining programming languages for industrial control.

Loop Update - *Servo Loops* in the SMLC systems are updated by the *Motherboard* at rates of between 500 and 2,000 times per second. At each *Loop Update*, (Loop Rate) the SMLC performs housekeeping operations such as updating the axis position and the output signals in addition to performing the real-time control algorithm for that servomotor.

Machine Sensor - Any of a number of types of ON-OFF sensors, like proximity switches or mechanical switches mounted to a machine.

MODBUS – MODBUS® Protocol is a messaging structure developed by Modicon in 1979, used to establish master-slave/client-server communication between intelligent devices. It is a de facto standard, truly open and the most widely used network protocol in the industrial manufacturing environment.

MODBUS/TCP – Modbus/TCP is an implementation of the MODBUS Protocol, allowing MODBUS messages to be transferred via Ethernet.

OPC – OLE for Process Control. A set of open standards for connectivity and interoperability of industrial automation and enterprise systems.

Pacemaker - A *servo* or *encoder axis* which transmits either its actual or commanded motion to other servo axes through the MotionDATA communication channel to another servo axis.

Pacemaker Encoder - An incremental encoder or device that generates *quadrature* signals which are used by other servo axes when they operate as *followers*.

Quadrature - Quadrature or "phase quadrature" signals are the most commonly used method of electronically determining or transmitting bi-directional position information. The two-quadrature signals are digital square waves, which have their cycles displaced 90 degrees (of the 360 electrical degrees in the repeated waveform). All four edges of the two digital signals are normally used for the maximum possible position resolution ("4x").

RTOS - Real-Time Operating System.

Registration Control - The act of maintaining a fixed position relationship between machine tooling and a product in the machine. Registration is normally measured by capturing the tooling position with respect to the product using a registration sensor of some type. It is controlled by phasing the tooling ahead or behind based on the difference between the actual and desired positional orientation.

Resolver - A position transducer used to determine the position of a motor. Resolvers are rotary transformer devices with analog interfaces. However, in ORMEC Motion Control systems which use resolvers, the servodrive decodes the resolver position digitally.

Servo (or Servomotor) - A motor which is controlled by comparing its measured position with its desired position.

Servodrive - A power unit necessary to control a servomotor.

Servo Loop - The act of controlling a servo by repeatedly observing its speed and position and adjusting its torque creates a "servo loop". With ServoWire Motion & Logic Controller Manual, these digital loops are "closed" at *loop update* rates of 250 to 4,000 times per second.

ServoWire Pro – ORMEC's Win32 based commissioning software for SoftMotion platforms including the SMLC. ServoWire Pro contains tools for configuring, monitoring, tuning and upgrading the firmware of SoftMotion based drives and products.

SMLC - ServoWire Motion & Logic Controller (SMLC) is ORMEC motion programming language which enhances industry IEC 61131-3 standard with additional built-in statements and pre-defined variables specifically intended for ServoWire Motion & Logic Control applications.

SoftMotion – Open, PC-based software for controlling servodrives that eliminates the need for motion control boards or standalone motion controllers.

TCP/IP – Transmission Control Protocol over Internet protocol. The de facto standard Ethernet protocol.

Tension - the magnitude of force uniformly distributed through a material as a result an external force on that material which constrains movement.

Tension Control – using Tension feedback to control the velocity of a servomotor.

Appendix A - SMLC Installation Diagrams

SMLC – Installation Dimensions





Figure 23 SMLC Mounting dimensions - height and width




Side view all.

Figure 24 SMLC Mounting dimensions – depth

Appendix B – System Wiring Drawings


ServoWire SDM Drives 120 ~ 460 VAC System Wiring




Notes:

- 1) The E-Stop interlock configuration shown assumes that the drive(s) is/are configured in ServoWire Pro to use IN3 as an E-Stop input and OUT5 as a Drive Ready indicator. Refer to the Operation chapter of this manual and the ServoWire Pro Help manual for further information.
- 2) The E-Stop indicator relay is customer supplied. Refer to Note 1.
- 3) The Drive Ready relay is customer supplied. **The Interlock and I/O power should be provided by separate power supplies to prevent inductive in-rush from the Drive Ready relay.**

ServoWire SMM Drives 120 ~ 460 VAC System Wiring



ServoWire SMM Drive 12 ~ 96 VDC System Wiring




Appendix C – SMLC Interface Cables & Accessories

Serial Communications Null Modem Cable to PC

This cable is used with the SMLC RS-232 serial connector and Windows Dial-up connections.

SMLC – J20		DB9 MALE	PC	
Data Carrier Detect (DCD)				
Receive Data (RD)		2 - 3	(TD)	Transmit Data
Transmit Data (TD)		3 - 2	(RD)	Receive Data
Data Terminal Ready (DTR)		4 - 6	(DSR)	Data Send Ready
Signal Ground (SG)		5 - 5	(SG)	Signal Ground
Data Send Ready (DSR)		6 - 4	(DTR)	Data Terminal Ready
Request To Send (RTS)		7 - 8	(CTS)	Clear To Send
Clear To Send (CTS)		8 - 7	(RTS)	Request To Send

The above pin-out will provide the best possible signaling between a SMLC and a PC allowing you to use hardware flow control (RTS/CTS). This type of cable requires that you enable hardware flow control.



Note: Not all Null modem cables are alike. Some Null Modem Cables will bypass hardware flow control. This type of cable adds a short between pin 1 and 6 on the same connector to fool the communication program to thinking that they are online.



Appendix D – ServoWire Drive Fault Codes

LED Hex	Code Decimal	ServoWire Drive “A” Fault Codes
A0	160	<p>The maximum continuous current output of the drive has been exceeded.</p> <p>Drive Over Current (RMS). The Drive shutdown with a overload fault.</p> <p><u>Under load or during acceleration:</u></p> <ul style="list-style-type: none"> • The most common cause for this fault is mechanical binding. Check the machine for excessive friction. -OR- • If this fault shows up when the machine is run at higher speeds, then the Drive and/or motor may be undersized for the application. <p><u>When enabling axis with Servomotor connected:</u></p> <ul style="list-style-type: none"> • Incorrect servomotor wiring. Check for proper wiring. On the drive power Terminal Block, the Ormec standard motor cable colors used are: U = Red, V = White, W = Black, Ground = Green and Silver. -OR- • Defective Servomotor - Replace Servomotor. <p><u>After applying control power with Servomotor disconnected:</u></p> <ul style="list-style-type: none"> • Defective Servodrive - Replace Servodrive.
A1	161	<p>The drive's peak current rating has been exceeded.</p> <p>Drive Over Current (Peak)</p> <p><u>Under load or during acceleration:</u></p> <ul style="list-style-type: none"> • The most common cause for this fault is mechanical binding. Check the machine for excessive friction. -OR- • If this fault shows up when the machine is run at higher speeds, then the Drive and/or motor may be undersized for the application. <p><u>When enabling the axis:</u></p> <ul style="list-style-type: none"> • The application program has not yet configured the drive. Configure the drives before changing to a torque-producing mode.
A2	161	<p>The drive power module detected over current, overtemp or under voltage.</p> <ul style="list-style-type: none"> • The Power Module’s self-protection has detected a short circuit, over current, over temperature, control supply under voltage. -OR- • An SCR soft-start circuit error has been detected on the SAC-SMM or SAC-SWM 225, 235 & 260 drives only. <p>Note: This fault is detected after the drive has been enabled.</p>
A3	163	<p>The bus voltage dropped below the software configured Minimum Bus Voltage.</p> <p>The bus voltage dropped below the drive configuration setting. Bus Power LED is OFF.</p> <p><u>When the drive is being or has been enabled:</u></p> <ul style="list-style-type: none"> • Main fuses blown or circuit breaker tripped. Correct main input power problem, and replace fuses or reset circuit breaker. • Input voltage does not match ServoWire Pro software setting. Decrease software setting or increase applied AC input voltage. • Defective Servodrive - Replace Servodrive.

LED Hex	Code Decimal	ServoWire Drive “A” Fault Codes
A4	164	<p>The bus voltage exceeded the software configured Maximum Bus Voltage.</p> <p>The bus voltage exceeded the drive configuration setting. The bus voltage is above the high voltage limit, which is calculated based on the lessor of the motor rated voltage and the drive maximum voltage.</p> <p><u>When power is applied to the main circuit:</u></p> <ul style="list-style-type: none"> • Applied voltage exceeds the Servomotor’s rating - Reduce applied voltage. • ServoWire Pro software settings for ServoWire Drive Input Voltage are lower than desired applied voltage – Increase setting in ServoWire Pro software. • Defective Servodrive – Replace Servodrive <p><u>When motor is in regeneration, or when drives share bus power.</u></p> <p>Regeneration may exist during deceleration, or during downward motion in a non-counterbalanced vertical application, or in a tensioned unwind application.</p> <ul style="list-style-type: none"> • A regenerative discharge resistor is required by the application but is not present- Install regenerative resistor, reduce inertial load, or reduce max speed and/or acceleration. • The regenerative resistor installed has been damaged and is no longer fully functional - Install higher-wattage regenerative resistor, and reduce inertial load, or reduce max speed and/or acceleration.
A5	165	<p>The drive type does not match the software configuration settings.</p> <p>SMLC has detected that the drive hardware does not match ServoWire Pro project settings.</p> <p><u>Either:</u></p> <ul style="list-style-type: none"> • Auxiliary feedback encoder is created in user program but drive does not have pacer (/P) hardware option. -OR- • Axis is configured for drive type SAC-SW_ but actual drive type is SAC-SM_ -OR- • Axis is configured for drive type SAC-SM_ but actual drive type is SAC-SW_. <p>SMLC may also indicate this by the exception # 1031, Error Message = Configured Drive type doesn't match actual drive hardware.</p>
A6	166	<p>Unable to enable torque before the drive setup parameters have been configured.</p> <ul style="list-style-type: none"> • An attempt was made to enable torque before the drive’s setup parameters have been configured. The drive setup parameters must be configured each time the drive’s control power cycles on, before the drive can be enabled.
A7	167	<p>Drive configuration is illegal while a motor is enabled.</p> <ul style="list-style-type: none"> • An attempt was made to write parameters for the 'Number of Poles ' or 'Resolution' to the drive while the drive was enabled. The drive must be disabled before changing these parameters. It is illegal to perform certain operations while a motor on the drive is enabled, such as changing the configuration of the drive.

LED Hex	Code Decimal	ServoWire Drive "A" Fault Codes
A8	168	<p>An Invalid commutation position was detected.</p> <p>A drive configured for a motor with an absolute encoder was commanded to enable when the absolute encoder was discharged, or while the commutation position was invalid, or the Absolute battery power output was toggled on a Drive configured for an incremental encoder. The commutation position is invalid on a drive configured for an absolute encoder motor when:</p> <ul style="list-style-type: none"> <input type="checkbox"/> The Drive is powered up, prior to drive configuration. <input type="checkbox"/> An open encoder line is detected. <input type="checkbox"/> During trapezoidal commutation. <input type="checkbox"/> "Number Of Poles" is written. <input type="checkbox"/> "Resolution" is written. <p>The commutation position becomes valid when the absolute encoder's position is read.</p>
A9	169	<p>The drive detected a phase loss.</p> <ul style="list-style-type: none"> • The drive detected the loss of a main power phase.
AA	170	<p>The drive Soft Start SCR did not turn on.</p> <p>The drive inrush current is greater than 0.5 amps or there is a low bus voltage (<50 VDC). Note: This is only checked when enabling the drive.</p> <p>The hardware switch from soft start mode to full power mode doesn't take place until after startup is complete, as evidenced by low inrush current and sufficient bus voltage. This error may be caused by:</p> <ul style="list-style-type: none"> • Enabling too soon after applying AC bus power. – Wait longer between disabling and reapplying AC bus power. • Low AC bus power input voltage so that BUS+ never reaches 50 VDC –Correct the AC bus power input voltage • The load on BUS+ and BUS- is drawing current as soon as AC bus power is applied. - Remove the load from BUS+ and BUS- (there should not be a load on BUS+ and BUS-, regen resistors are connected to BUS- and RG.
AB	171	Unused
AC	172	<p>Drive Overtemp or Drive Inrush Resister Current failure.</p> <ul style="list-style-type: none"> • An over-temperature condition was detected in the drive power-block, or a failure of the inrush current resistor. This fault is detected when the drive is being enabled.
AD	173	<p>The drive detected an E-Stop indication.</p> <ul style="list-style-type: none"> • A drive emergency stop was detected. This requires that the drive be configured to use one of the general purpose inputs as an E-Stop input. See: Emergency Stop / Quick Stop Inputs.
AE	174	Host PC driver software upgrade is required.
AF	175	Unused

LED Hex	Code Decimal	ServoWire Drive “b” Fault Codes
b0	176	<p>The checksum on the downloaded code was incorrect. Try again.</p> <ul style="list-style-type: none"> The checksum calculation performed on the downloaded code was incorrect. The download has been aborted. Try again.
b1	177	<p>The download code was not recognized. The wrong file was used.</p> <ul style="list-style-type: none"> The ServoWire drive does not recognize the download file format. Usually caused by wrong file being sent to the drive. The drive firmware may be too old to recognize this format.
b2	178	<p>Downloaded code not compatible with this drive.</p> <ul style="list-style-type: none"> The downloaded code is not designed for this drive hardware, but rather for a different drive hardware. Obtain the correct file and try again.
b3	179	Internal firmware program checksum error, reload drive firmware.
b4-bF	180-191	Unused

LED Hex	Code Decimal	Description - ServoWire Drive “C” Fault Codes
C0	192	<p>The position following error for an axis exceeded its PosErrFault limit.</p> <p>LAG_FAULT (Position Error) Generation The most common cause for this fault is mechanical binding. Check the machine for excessive friction. LAG_FAULT is the axis configuration property that defines the allowable magnitude of following error that will be tolerated and the axis will continue to operate in a non-faulted state. If this following error setpoint is exceed, an axis fault will occur, and the fault function OP_FAULT will be called. OnFault is invoked when an axis detects a fault condition. The drive will fault out and the drive status display will show a hexadecimal " C 0 " code = Lag Fault . OP_FAULT returns the fault code in progress on an axis, and in this case a decimal "192" is returned.</p> <p> ServoWire Pro, "Axis Properties / Settings" Setup screen, allows the user to define the magnitude of LAG (position error) in counts that will be tolerated before a fault is generated.</p>
Blank	192	<p>The position following error for an axis exceeded its PosErrAlarm limit.</p> <p>LAG_ALARM (Position Error) Notification LAG_ALARM is the configuration property that defines the allowable magnitude of following error for the axis to be considered "in position". If this following error setpoint is exceeded, an axis alarm will occur, and the alarm function OP_ALARM will be called. OP_ALARM is invoked when an axis detects an alarm condition. OP_ALARM returns the current alarm code for an axis. The axis will NOT go into a Fault state for exceeding this position error threshold. The drive will NOT display any codes.</p> <p> ServoWire Pro, "Axis Properties / Settings" Setup screen, allows the user to define the magnitude of LAG (position error) in counts that will be tolerated before an alarm is generated.</p>

LED Hex	Code Decimal	ServoWire Drive "C" Fault Codes
C1	193	The commanded speed exceeded the software configured speed limit. The commanded speed exceeded the application - specified limit for Speed Maximum.
C2	194	The actual (feedback) speed exceeded the software configured speed limit. The actual (feedback) speed exceeded the application-specified limit for Speed Maximum.
C3	195	Motion was commanded further into a travel limit, while still active. Motion was commanded further into a travel limit while that travel limit was asserted.
C4	196	Unused
C5	197	The software configured Loop Rate was too high to finish the control loop. The specified LoopRate was too high to finish control loop processing.
C6	198	Missing MotionData.
C7	199	Motion Segment Overflow.
C8	200	Missing Motion Table.
C9	201	Unexpected Off-line, no isochronous feedback. SMLC has a built in tolerance for the maximum number of (3) consecutive ServoWire isochronous communication feedback packets that can be missed per axis before faulting out that axis. When this limit is reached then the drive fault "C9" is generated for that axis. There is a variety of reasons that can cause a missed 1394 isochronous data packet, but the most common problem is electrical static discharge (noise). It is strongly recommended that the application developer read the Ormec application paper on "Shielding and Ground Electrical Panels" that is available on the web site www.Ormec.com
CA	202	1394 Network driver failure. No longer getting an once-per-looprate update information from the Ormec 1394 Bus Driver (Orm1394Bus).
CB	203	Pacer Backup Compensation Overflow. See: Pacer Backup Compensation.

LED Hex	Code Decimal	ServoWire Drive "C" Fault Codes
CC	204	<p>Invalid MotionData Configuration - MotionData configured in a Loop.</p> <p>SMLC provides the ability to electronically GEAR multiple servomotors together, or GEAR multiple servomotors to a common source of position information such as an axis encoder mounted to a machine. This is accomplished with MotionData communications link, which transmits real-time motion information between axes at each position loop update. The MotionData Network is a daisy-chained, one-way, error-correcting communications link, commonly starting with the lowest numbered axis in the system and proceeding to the highest. This is an application program error. Call your application programmer.</p> <ul style="list-style-type: none"> • An axis is attempting to use itself as the pacer (gearing off itself). -OR- • MotionData is configured in a continues closed loop.
CD	205	Unused
CE	206	Unused
CF	207	Unused

LED Hex	Code Decimal	ServoWire Drive "E" Fault Codes
E0	224	<p>Incompatible ServoWire Protocol.</p> <ul style="list-style-type: none"> • The ServoWire communications protocol in the drive is not compatible with the one in SMLC. Either the drive's firmware should be changed to a version that is compatible with ServoWire SM RTX, or ServoWire SM RTX must be changed to a version that is compatible with the ServoWire SMM Drive.
E1	225	<p>The host PC unexpectedly stopped providing isochronous commands to the drive.</p> <ul style="list-style-type: none"> • This normally occurs when the servodrive has control power, but the SMLC loses power, or the IEEE 1394 Network interface hardware fails. In either case, once the cause has been corrected, the fault can be cleared by the application program (or by cycling power on the servodrive). There is a variety of reasons that can cause a missed 1394 isochronous data packet, but the most common problem is electrical static discharge (noise). It is recommended that the application developer read the ORMEC application paper on "Shielding and Ground Electrical Panels" that is available on the web site www.Ormec.com
E2	226	<p>Isochronous Arbitration Failure.</p> <ul style="list-style-type: none"> • One possible cause is the Loop Rate is set too high to allow all the drives on the 1394 network to send there isochronous data packets. Lower the LoopRate.

LED Hex	Code Decimal	Description - ServoWire Drive "E" Fault Codes
E3	227	<p>Isochronous data not changing. (Watchdog timeout).</p> <ul style="list-style-type: none"> The ServoWire Isochronous communications watchdog bit has not changed state within the allotted time. The ServoWire drive shut itself down because it lost communication with the SMLC. One possible cause is the application program crashed causing the communication drivers to locked up. Check that the SMLC application program is running correctly. There is a variety of reasons that can cause a watchdog timeout, but the most common problem is electrical static discharge (noise). <p>It is recommended that the application developer read the ORMEC application paper on "Shielding and Ground Electrical Panels" that is available on the web site www.Ormec.com.</p>
E4	228	<p>ServoWire Initialization Error.</p> <p>A hardware error was detected when initializing the IEEE 1394 communications controller circuitry.</p>
E5	229	<p>Host PC Power Loss or unexpected failure.</p> <ul style="list-style-type: none"> The drive internal watchdog has timed out due to either the loss of ServoWire network power (usually due to loss of PC power) or an unexpected failure.
E6	230	<p>No ServoWire 1394 Network power.</p> <ul style="list-style-type: none"> The drive is powered up and is not detecting ServoWire 1394 network power. Power for the ServoWire interface is supplied by the SMLC (8 – 40 Vdc). Possible causes include: The ServoWire cable is not connected to the drive and/or the SMLC. Be sure to verify that all the cables in the drive 1394 network are properly connected. <p>The SMLC is turned off and/or not supplying power to the ServoWire 1394 network.</p>
E7	231	Unused
E8	232	<p>Duplicate Drive Identification number.</p> <ul style="list-style-type: none"> The SMLC has detected more than one drive with same Axis identification (ID) number on the network. <p>The drive ID number is changed by pressing the push-button located on the top of the drive. The drive ID number can be changed after each power-up, SMM Drives - before torque has been enabled. SWM Drives - before the drive is configured. (Three red LED's are flashing The push-button is then disabled.</p>
E9-EF	233-239	Unused

LED Hex	Code Decimal	ServoWire Drive “F” Fault Codes
F0	240	<p>The motor's rating for continuous current has been exceeded.</p> <ul style="list-style-type: none"> The motor's rating for continuous current has been exceeded by the actual RMS current for longer than allowed by the thermal time constant of the motor.
F1	241	<p>Primary Axis - Feedback device, open wire failure.</p> <ul style="list-style-type: none"> At least one encoder or resolver feedback channel for the motor is not connected properly. Check the motor feedback cable for damage. -OR- Resolver Feedback Only: The optional plug-in module SAC-SM-RES, used with a SAC-SMM drive is required to support a resolver motor. Resolver open wire debounce detected. During hard accelerations the Resolver to Digital converter may issue a false error. ServoWire Pro, "Feedback Option Board / Open wire debounce time" Setup screen, allows the user to define the amount of debounce time. Increasing the debounce time can eliminate that extraneous error. Absolute Encoder Feedback Only: The optional /A, used with a SAC-SW ### /A drive is required to support an absolute motor. The Absolute Encoder needs to be reset. See: Absolute Encoder Reset.
F2	242	<p>Auxiliary Axis - Feedback device, open wire failure.</p> <ul style="list-style-type: none"> At least one encoder or resolver feedback channel for an auxiliary (pacer) axis feedback is not connected properly. Check the motor feedback cable for damage. <p>Note: Fault F2 = Auxiliary feedback Open Wire will not cause the primary axis to lose torque.</p>
F3 F3_1 F3_2 F3_3	243	<p>The hall track feedback from the motor is improperly wired.</p> <p>The hall track encoder feedback from the motor is improperly wired. An unexpected combination of Hall inputs has occurred. Differential or single-ended input, commutation feedback channels U, V and W from the motor encoder feedback connector. The U, V and W (pins 7, 9 & 11) inputs are intended for use with single ended commutation feedback. If the feedback signals are open collector outputs, external biasing hardware may be required. The U', V' and W' (pins 8, 10 & 12) inputs are internally biased and no connection or external circuitry is required for use with single ended feedback. Invalid states detected: U,V,W all ON at the same time. U,V,W all OFF at the same time. U',V',W' all ON at the same time. U',V',W' all OFF at the same time.</p> <p>When enabling axis:</p> <ul style="list-style-type: none"> Bad feedback cable - Check pins above. Wrong axis feedback type selected in ServoWire Pro Setup software settings – Correct software. <p>In some cases a 2nd digit is used to provide more information:</p> <p>F3_1 – Invalid Hall state on differential inputs F3_2 – Invalid Hall state on D-Series motor interface F3_3 – Invalid Hall state on H-Series motor interface</p>

LED Hex	Code Decimal	Description - ServoWire Drive "F" Fault Codes
F4	244	<p>The motor over temperature sensor is open, indicating an overtemp condition.</p> <p>The thermal contact has opened (pins 19 & 20) indicating that the motor is over temperature. This condition can not be reset until the motor has sufficiently cooled.</p> <p><u>When the motor is hot:</u></p> <ul style="list-style-type: none"> • Motor is overloaded - Reduce motor load • Excessive ambient temperature - Reduce ambient temperature to 25oC <p><u>When the motor is cool to the touch:</u></p> <ul style="list-style-type: none"> • Faulty motor feedback wiring - Check cable and all termination points. • Defective thermal switch in motor - Disconnect motor and test for continuity at motor pins. • Motor has no thermal switch, and ServoWire Setup software settings are configured to expect a closed contact. - Disable Thermal Contact in ServoWire Setup Axis Configuration. • Defective Servodrive - Replace Servodrive.
F5	245	<p>The drive firmware does not recognize an installed feedback option board.</p> <p>The SAC-SMM drive has detected an installed option module, but does not recognize and/or support that module type.</p> <ul style="list-style-type: none"> • Not supported by the drive firmware - Verify that the drive firmware revision supports the option module, and update as needed. • Improper option module installation - Reinstall the option module and verify it is properly connected to the drive. • Defective option module - Replace the option module.
F6	246	<p>The motor overtemp software configuration does not match the actual wiring.</p> <ul style="list-style-type: none"> • The motor configuration indicates that there is no over temperature sensor, but an over temperature sensor was detected by the drive.
F7	247	<p>Serial Encoder Alarm.</p> <p>When using an Yaskawa Sigma 2 An alarm bit has been returned by the Sigma 2 encoder.</p> <ul style="list-style-type: none"> • Check connections & feedback cable for good electrical connection. • Try cycling the ServoWire Drive control power. • Defective encoder feedback - Replace Servomotor.
F7_1	247	<p>Incremental Encoder error</p> <p>When using an H-series motor with an incremental encoder the encoder has reported an error. The error can only be cleared by power cycling the motor, which can only be done by power cycling the drive.</p>
F7_2	247	<p>Absolute encoder overspeed error</p> <p>When using an H-series motor, the absolute encoder has reported an error. The error can only be cleared by power cycling the motor, which can only be done by power cycling the drive.</p>
F7_3	247	<p>Absolute encoder absolute error</p> <p>Cycling encoder power clears this error.</p>

F7_4	247	<p>Absolute encoder backup power failure</p> <p>Backup power has failed and absolute position has been lost. Use the MC_AbsReset function block to clear this error. The absolute encoder can also be reset in SwMonitor in ServoWire Pro v3.6 or later.</p>
F7_5	247	<p>Absolute encoder generic error</p> <p>This is a generic error which can be cleared using the MC_AbsReset function block. The absolute encoder can also be reset in SwMonitor in ServoWire Pro v3.6 or later.</p>
F7_6	247	<p>Absolute encoder over temperature error</p> <p>This error indicates that the encoder is too hot and should be cooled. Operation may continue after clearing the error with the MC_Reset function block but is not recommended. The error will only be reported once per drive power cycle.</p>
F7_7	247	<p>Absolute encoder battery low error</p> <p>This error indicates that the encoder backup battery power is getting low and should be replaced. Operation may continue after clearing the drive error using the MC_Reset function block. The error will only be reported once per drive power cycle.</p>
F7_8	247	<p>Found unknown type of Sigma II encoder</p>
F8	248	<p>Unsupported Serial Encoder detected.</p> <ul style="list-style-type: none"> • Unsupported encoder feedback type detected - Replace servomotor to a supported type. • Not supported by the drive firmware - Verify that the drive firmware revision supports the Serial Encoder, and update as needed.
F8_2	248	<p>Unsupported Serial Encoder detected.</p> <p>Data offset error</p>
F9-FF	247-255	Unused

LED Hex	Code Decimal	Other ServoWire Drive Fault Codes
70	112	Axis Off-line <ul style="list-style-type: none"> This can be caused by shutting off the Servodrive Control power. Check that the servodrive has control power.
71	113	Reference Generation Conflict (Internal error)
74	116	Unsupported feedback device <ul style="list-style-type: none"> The drive firmware does not support this feedback type. Upgrade the drive firmware
75	117	Tension Max The actual measured tension is greater than OP_TEN_MAX and the application (OP_TEN_LIM_ACTION) is configured to generate a fault if this occurs.
76	118	Tension Min The actual measured tension is less than OP_TEN_MIN and the application (OP_TEN_LIM_ACTION) is configured to generate a fault if this occurs.
Internal Errors		Internal errors may require cycling the servodrive control power to clear the fault. If the problem recurs or does not clear, contact ORMEC Application Support at (585) 385-3520 or via e-mail at support@ORMEC.com. Please have your Support ID available when you call or reference it in your e-mail message. Drive faults 70 - 9F may require cycling the drive control power to clear the fault. The application program can clear all other faults (after the cause of the fault has been cleared).
90	144	This failure is normal during ServoWire cable pulls.